

A Chairmaker Who Changed the Craft

Mirka
DEROS



POPULAR Woodworking MAGAZINE

April 2015 ■ #217

Inlaid Art Deco Side Table Turned Torpedo Legs & Holly Details

Tapered Sliding
Dovetails
Hand Tools Get the
Job Done – Fast

Stool Sampler
Learn 8 Joints &
Bent Lamination

Fire & Wax
Charred Finish:
Simple & Fun

Asian-Inspired
An Elegant Lamp in
Wood & Rice Paper



popularwoodworking.com

MIRKA

Introducing **Mirka® DEROS**

Introductory Offer!
For information visit,
www.mirka-deros.com



Unequalled Performance. Brushless DC Power.

Introducing Mirka® DEROS, the first random orbital electric sander using advanced brushless DC motor technology, without the need for an external power transformer. Performance unequalled by any competitive electric tool can now be found within reach of any standard 110 volt outlet.

Visit our website at www.mirka-deros.com for more information on this revolutionary sanding machine.

Mirka Abrasives, Inc. • 7950 Bavaria Road, Twinsburg, Ohio 44087 • tel 800-843-3904 • fax 800-626-6970 • www.mirka.com

CARD #31 or go to PWFREEINFO.COM

CONTENTS

APRIL 2015



30



33



50

FEATURES

22 Ruhlmann Tabouret

This side table, inspired by the stunning Art Deco work of Émile-Jacques Ruhlmann, features torped-shaped holly and mahogany legs, holly inlay and mahogany veneer.

BY MARIO RODRIGUEZ

ONLINE ► Small & Simple

Build an understated Shaker one-drawer side table with these free plans.

popularwoodworking.com/apr15

30 Tapered Sliding Dovetails

Discover how to cut this strong and versatile traditional joint quickly by hand; you probably already own the tools.

BY FRANK STRAZZA

ONLINE ► Watch & Learn

Watch a video of how a tapered sliding dovetail is made by hand.

popularwoodworking.com/apr15

33 Kumiko Lamp

The latticework (or kumiko) in this Japanese-inspired lamp is made from many small bits of wood – but some clever jigs simplify the process to make perfectly sized pieces.

BY RANEY NELSON

ONLINE ► A Master Reflects

Toshio Odate reflects on his traditional Japanese woodworking apprenticeship.

popularwoodworking.com/apr15

40 Charred Finish

With just a blowtorch, wax and a scouring pad, create a beautiful black finish with this blazingly simple technique.

BY SETH GOULD

ONLINE ► Black Ops

Discover another technique to ebonize wood for a beautiful black finish.

popularwoodworking.com/apr15

42 Curve Appeal

This skill-building stool employs eight different joints, bent lamination and several hand-shaped parts. The result is a seat that looks great in your kitchen or shop.

BY NEIL CRONK

ONLINE ► Free Plan

Download a free SketchUp model of this project.

popularwoodworking.com/apr15

50 Make a Revolution From a Tree

With a single chair, a book and years of research, a curious attorney changed the (woodworking) world and inspired a generation of green woodworkers.

BY CHRISTOPHER SCHWARZ

ONLINE ► Log to Lumber

Peter Follansbee writes about the best oak money can't buy.


popularwoodworking.com/apr15




40

CONTENTS

APRIL 2015



10



16



64

REGULARS

4 Enter the 2015 PWM Excellence Awards

OUT ON A LIMB

BY MEGAN FITZPATRICK

6 The Ins & Outs Of Workbench Joints

LETTERS

FROM OUR READERS

10 Forstner Bit In a Hand Brace? Sure!

TRICKS OF THE TRADE

FROM OUR READERS

ONLINE ► More Tricks

Read and watch some of our favorite tricks.

popularwoodworking.com/tricks

12 Mirka Deros Random-orbit Sander

TOOL TEST

BY THE EDITORS

ONLINE ► Tool Test Archives

We have many tool reviews available for free on our web site.

popularwoodworking.com/tools

16 Killer Wood

DESIGN MATTERS

BY GEORGE R. WALKER

58 Work Begun

ARTS & MYSTERIES

BY PETER FOLLANSBEE

62 Why is Finishing So Difficult?

FLEXNER ON FINISHING

BY BOB FLEXNER

64 Why I Love Ikea

END GRAIN

BY EDWARD SUTER



62



58

POPULAR Woodworking MAGAZINE

Number 217, April 2015. *Popular Woodworking Magazine* (ISSN 0884-8823, USPS 752-250) is published 7 times a year, February, April, June, August, October, November and December, which may include an occasional special, combined or expanded issue that may count as two issues, by F+W Media. Editorial and advertising offices are located at 8469 Blue Ash Road, Suite #100, Cincinnati, OH 45236. Unsolicited manuscripts, photographs and artwork should include ample postage on a self-addressed, stamped envelope (SASE); otherwise they will not be returned. Subscription rates: A year's subscription (7 issues) is \$24.95; outside of the U.S. add \$7/year. Canada Publications Mail Agreement No. 40025316. Canadian return address: 2835 Kew Drive, Windsor, ON N8T 3B7. Copyright 2015 by *Popular Woodworking Magazine*. Periodicals postage paid at Cincinnati, Ohio, and additional mailing offices. Postmaster: Send all address changes to *Popular Woodworking Magazine*, P.O. Box 420235, Palm Coast, FL 32142-0235 Canada GST Reg. #R132594716. Produced and printed in the U.S.A.

**QUALITY WOODWORKING TOOLS •
SUPPLIES • ADVICE®**

Over 20,000 Woodworking Products!

- Hand & Power Tools
- Power Tool Accessories
- Routers & Accessories
- Carving Tools & Chisels
- Workbenches
- Hardwoods & Exotics
- Sanding & Scraping
- Woodburning
- Vises & Clamps
- Files & Rasps
- Project Kits & Supplies
- Clock Supplies
- Planes & Saws
- Woodboring Tools
- Sharpening Supplies
- Finishing Supplies
- Safety Equipment
- Woodturning
- Hardware
- Marking & Measuring
- Cabinetmaking Supplies
- Shop Accessories
- Books & DVDs

Woodcraft offers exclusive products to our customers!

Wood River®



WOODCRAFTPlans.com

WOODCRAFT
magazine

Woodcraft Magazine Publishes
Six Great Issues A Year!

Classic®
PROJECT PLANS

Classic®
SHOP PLANS



For A Free Catalog Or To Find Your Local Woodcraft Store, Visit woodcraft.com Or Call 800-225-1153. 15PW04P
For Information On Woodcraft Retail Franchise Opportunities, Visit woodcraftfranchise.com

APRIL 2015, VOL. 35, NO. 2
popularwoodworking.com
EDITORIAL OFFICES 513-531-2690

Enter the 2015 PWM Excellence Awards

The submission period commences on April 1 for the 2015 PWM Excellence Awards; entries will be accepted through June 14 at popularwoodworking.com/2015readerexcellence.

This will be the third year we've sponsored the awards. What I've liked most about them is seeing and sharing the great work produced by *Popular Woodworking* readers. And I want to see more of it! I encourage all of you to submit your best work for the 2015 awards. The six winners will be featured in the November 2015 issue, and all entries are available for viewing online for Readers' Choice voting.

The Grand-prize Winner will receive a check for \$1,000. Each of the five Editors' Choice winners and the Readers' Choice entry with the highest number of votes overall win a \$100 gift certificate to ShopWoodworking.com.

You can enter up to five pieces total in the five following categories:

- Casework, Cabinets & Bookcases
- Seating
- Tables
- Boxes & Smalls (a "small" might be, for example, a beautiful shop-made tool or wooden toy)
- Turnings, Carvings & Objets d'Art ("objets" encompass wall-hung art pieces, sculpture, wooden jewelry, etc.).

Note that you can submit already completed work for consideration; we're not expecting you to build a Roentgen-style cabinet in the next three months (but if you can actually

pull that off, well, do get in touch with me about writing an article).

The editors and contributing editors to *Popular Woodworking Magazine* will select the Grand-prize Winner, plus the winner in each of the five categories. Your online voting determines the Readers' Choice winner (voting opens June 17).

Gary Staple, of Halifax County, Nova Scotia, was the grand-prize winner in 2014 (his "Cherry Blossom Tea Case" is pictured here). I hope to meet him in person Sept. 25, at Woodworking in America 2015 in Kansas City, Mo.

Autumn Doucet, of Wenatchee, Wash., was our inaugural winner in 2013 for her "Figured Cherry Chest"; she not only won a trip to join

us at Woodworking in America 2014, we featured her lovely mahogany and ebony jewelry box with mother-of-pearl and abalone inlay in the April 2014 issue (#210).

Plus, the PWM Excellence Awards have led to articles by other entrants, including Peter Marcucci (who shared "Recreating Rohlfs" in the February 2015 issue, #216), and some yet to come.

So...our next big winner and featured woodworking author just might be you!

You'll find all the contest details, as well as directions on how to enter, on our web site at popularwoodworking.com/2015readerexcellence. PWM



Megan Fitzpatrick

GROUP PUBLISHER ■ Jamie Markle
jamie.markle@fwcommunity.com, x11452
GROUP EDITORIAL DIRECTOR &
EDITOR ■ Megan Fitzpatrick
megan.fitzpatrick@fwcommunity.com, x11348
SENIOR ART DIRECTOR ■ Daniel T. Pessell
daniel.pessell@fwcommunity.com, x11396
SENIOR MANAGING EDITOR ■ Michael Wallace
mike.wallace@fwcommunity.com, x11407
CONTRIBUTING EDITORS ■
Bob Flexner, Christopher Schwarz,
Steve Shanesy
PHOTOGRAPHER ■ Al Parrish
PROJECT ILLUSTRATOR ■ Donna R. Hill
ONLINE CONTENT DEVELOPMENT MANAGER ■
David Thiel
david.thiel@fwcommunity.com, x11255
CONTENT EDITOR, BOOKS ■ Scott Francis
scott.francis@fwcommunity.com, x11327

F+W MEDIA, INC.
CHAIRMAN & CEO ■ David Nussbaum
COO & CFO ■ James Ogle
PRESIDENT ■ Sara Domville
CHIEF DIGITAL OFFICER ■ Chad Phelps
SENIOR VICE PRESIDENT,
OPERATIONS ■ Phil Graham
VICE PRESIDENT, COMMUNICATIONS ■ Stacie Berger

ADVERTISING
VICE PRESIDENT, SALES ■ Dave Davel
ADVERTISING DIRECTOR ■ Don Schroder
331 N. Arch St., Allentown, PA 18104
TEL. 610-821-4425; FAX. 610-821-7884
d.schroder@verizon.net
ADVERTISING SALES
COORDINATOR ■ Connie Kostrzewa
TEL. 715-445-4612 x13883
connie.kostrzewa@fwcommunity.com

NEWSSTAND
For newsstand sales, contact Scott T. Hill:
scott.hill@procirc.com

SUBSCRIPTION SERVICES:
Subscription inquiries, orders and address changes can be made at popularwoodworking.com (click on "Customer Service"). Or by mail: *Popular Woodworking Magazine*, P.O. Box 420235, Palm Coast, FL 32142-0235. Or call 386-246-3369. Include your address with all inquiries. Allow 6 to 8 weeks for delivery.

NEWSSTAND DISTRIBUTION:
Curtis Circulation Co., 730 River Road, New Milford, NJ 07646. PHONE: 201-634-7400. FAX: 201-634-7499.

BACK ISSUES are available. Call 800-258-0929 for pricing or visit shopwoodworking.com. Send check or money order to: *Popular Woodworking Magazine* Back Issues, F+W Products, 700 E. State St., Iola, WI 54990. Please specify publication, month and year.

Copyright ©2015 by F+W, A Content + eCommerce Company. All rights reserved. *Popular Woodworking Magazine* is a registered trademark of F+W, A Content + eCommerce Company.



TRACK SAW

- Motor: 120V, 9A, 1100 watt, 5500 RPM
- Blade diameter: 160mm (6¼")
- Cutting capacity:
With track: 1⅜" @ 90°, 1⅞" @ 45°
Without track: 2⅝" @ 90°, 1⅞" @ 45°



W1835 Track Saw only
D4363 Accessory Pack **D4362** Guide Rails

14" BANDSAW

- Motor: 1 HP, 110V/220V
- Precision-ground cast iron table size: 14" x 14" x 1½"
- Blade size: 93½" (⅞" to ¾" wide)
- Cutting capacity 13½" (throat)
- Cast iron frame and wheels
- Ball bearing blade guides
- Includes fence and miter gauge

Feature packed, and an incredible value



W1706 14" Bandsaw

PLANER MOULDER with Stand

- Motor: 2 HP, 240V, single-phase, 10.8A, 3450 RPM
- Precision-ground cast iron table size: 14⅞" x 10" x ⅞"
- Max planing width: 7"
- Max planing height: 7½"
- Cuts per minute: 14,000
- 2 HSS knives



W1812 Planer Moulder with Stand

10" TABLE SAWS with Riving Knife

- Motor: 3 HP, 220V, single-phase motor
- Precision-ground cast iron table size: 27" x 40¼"; (W1819) 53⅝" with extension; (W1820) 74" with extension
- Max. rip capacity: (W1819) 29½", (W1820) 50"
- Camlock fence with HDPE face



W1819 10" Table Saw
W1820 10" Table Saw with Long Ext. Table

¾ HP 13" BENCH-TOP DRILL PRESS

- Motor: ¾ HP, 110V, 1725 RPM
- Overall height: 38"
- Spindle travel: 3¼"
- Swing: 13¼"
- Drill chuck: ⅝"
- Speeds: 12, 250–3050 RPM
- Table: Round 12⅞" dia.
- Table swing: 360°
- Table tilt: 45° L & 45° R

PATENT OWNED BY WOODSTOCK INTERNATIONAL INC.



W1668 ¾ HP 13" Bench-Top Drill Press

6" x 12" HEAVY-DUTY COMBINATION SANDER

- Motor: 1½ HP, 120V, single-phase, 10.5A, 1725 RPM
- Precision-ground cast iron tables (2)
- Sanding belt size: 6" x 48"
- Belt Speed: 1066 FPM
- Disc size: 12"
- Disc speed: 1725 RPM



W1712 6" x 12" HD Combination Sander

OSCILLATING SPINDLE SANDER

- Motor: ½ HP, 120V, 3.5A
- 58 oscillations per minute
- Stroke length: ⅝"
- Sanding drum length: 4½"
- 2000 RPM (½" spindle)
- Table size: 15" L x 11½" W
- Dust port size: 1½"
- Switch: Paddle ON/OFF with disabling key
- CSA certified meeting CSA C22.2 #71.2-10 and UL 987-7 standards

VERY POPULAR!



W1831 Oscillating Spindle Sander

WALL DUST COLLECTOR

- Motor: 1 HP, 110V/220V, single-phase
- Air suction capacity: 537 CFM
- Bag capacity: 2 cubic feet
- Standard bag filtration: 2.5 micron
- Static pressure: 7.2"



W1826 Wall Dust Collector

3-SPEED HANGING AIR FILTER

- Motor: ⅞ HP, 120V, 60Hz, 1A, single-phase
- Air flow: 260, 362, and 409 CFM
- Outer filter: 5.0 micron
- Inner filter: 1.0 micron



W1830 Hanging Air Filter

WOODSTOCK® INTERNATIONAL, INC. IS ALSO HOME TO ROMAN CARBIDE®, PLANER PAL®, JOINTER PAL®, AND MANY OTHER FINE BRANDS. PLEASE VISIT OUR WEBSITE OR CALL TOLL FREE TO FIND AN AUTHORIZED DEALER NEAR YOU.

SHOPFOX.BIZ

sales@shopfox.biz WHOLESALE ONLY



1-800-840-8420

SHOP FOX® is a registered trademark of Woodstock® International, Inc.

The Ins & Outs of Workbench Joints

I've finally started on a workbench from the "Build a Sturdy Workbench in Two Days" DVD, but I have a question about the stretchers. Is there a particular reason why the stretcher joints are on the inside rather than the outside?

Naveen Gogineni
Damascus, Maryland


Naveen,
The reason the joinery is on the interior of the legs is visual.

For the long stretcher, it makes the bench look more like a traditional bench with a mortise-and-tenon base. It also helps to hide any gaps in the joinery.

For the short stretchers, it insets the short stretcher and adds shadow lines.

Feel free to put the joinery on the outside if you prefer.

Christopher Schwarz,
contributing editor



Keep it in the Pink

I enjoyed Bob Flexner's article on teak oil in the February 2015 issue (#216), especially the UV-resistance portion.

I recently procured a large cherry tree that had fallen in a farmer's field. I had it cut into boards and dried them, and I am in the process of learning how to make furniture.

I have not found a way to keep the finished products from darkening. I don't particularly mind the darkening result, but my wife does.

More importantly, if something is placed on the surface (flower pot, etc.) it shields the wood below it from sunlight

and leaves a surface that is not uniform. I have finished the pieces so far with shellac, followed by multiple coats of water-based polyurethane.

Do you have any suggestions or references that might be useful?

Dean Birzele
Elkhart, Indiana

Dean,
Funny—most woodworkers want to know how to make cherry darken to the rich rust-red color of old cherry faster than just letting it age naturally. (There's no good way to do this.)

You're the only person I've come across who wants to keep the cherry its natural

pinkish color. Unfortunately, there's no good way to do this, either.

The cause of the darkening is exposure to oxygen and light, which speeds the oxidation. You can reduce exposure to light, but not oxygen.

So no matter what you do, the cherry is going to darken.

You can apply a number of coats of UV-resistant marine varnish from a marina store (or online) to slow the darkening. As I showed in the teak-oil article, varnishes from home centers aren't effective, no matter what their claims.

But I don't think you're going to like this solution. Marine varnishes are glossy to reflect as much of the light as possible, and they are more effective with more coats. You're going to end up with a thick, glossy finish that will not stop the wood from darkening slowly anyway. I suggest you experiment on scrap wood.

Neither shellac nor water-based polyurethane offer significant UV resistance.

As for the flower pot, I suggest you move it to different locations every now and then.

Bob Flexner, contributing editor

Erasing Makers' Marks

I recently read your article "Make Your Mark" (December 2014, issue #215) and took away a few things I will incorporate into my routine. I did, however, have a question: When do you remove the marks?

If the marks make it less likely to make a mistake during final assembly, do you wait until after glue-up and handplane or scrape them off? Or do you remove them just prior to assembly and just keep them in order?


Glen Farmer III
via e-mail

Glen,
I remove marks after assembly. You generally have to plane every surface after assembly anyway to level joints.

Before planing I remove most of the pencil marks with alcohol. That makes it easier to plane away the marks.

Christopher Schwarz,
contributing editor

CONTINUED ON PAGE 8



Our Annual Hardware Catalog is Now Available.

View the full catalog online at www.leevalley.com or download it through the Lee Valley Library app available for iPad®, iPod®, iPhone® or Android™ devices.

1-800-683-8170

www.leevalley.com

Find us on:



Lee Valley & Veritas®

CARD #28 or go to PWFFREEINFO.COM

Your Source For
Unfinished Wood
Components



Same Day Shipping

1000+ Product Line

18+ Wood Species

Custom & Millwork Services

CAD Catalog

No Minimum Order



Request a Free Catalog

1.866.963.5576

www.customlegs.com

CARD #36 or go to PWFFREEINFO.COM

SUPER PINNER

NEW GREX® P650LX 2" 23 GAUGE HEADLESS PINNER

THE BEST NOW EVEN BETTER

GreX continues to be ahead of the game with the P650LX - the latest addition to our comprehensive line of 23 Gauge Headless Pinners. As others try to follow, we have once again proven we're the leaders in pin nailer innovation. You can still rely on the same award winning robust build quality that users have **trusted for over 15 years**. The difference is in the details, so learn how GreX precision crafted tools just work better and longer for you. **Now explore.**

- **Extra Powerful** motor with all-new nose design for an even more robust tool to drive the longest pins into the hardest woods at lower air pressures.
- The larger motor means you can use **smaller compressors** that have difficulty maintaining higher air pressures.
- **Contact Safety** with an integrated **Auto Lock-Out** alerts you when 10 pins remain; prevents dry firing and empty holes.
- Patent pending all-new **One-Touch Over-Ride** lets you drive the remaining Auto Lock-Out pins with just a single touch.
- A reversible durable hardened **Steel Belt Hook** helps keep your tool easily accessible when you're working on a ladder.



P650LX
2" 23 Gauge
Headless
Pinner

FIND YOUR DEALER | www.grextools.com 888-447-3926 905-838-4887

AVAILABLE
MARCH 2015

CARD #20 or go to PWFFREEINFO.COM

Must One Always Sand?

In “The Essential Woodworker” (Lost Art Press), Robert Wearing recommends planing and scraping, then sanding.

I have a DVD from Frank Klausz in which he works on a cherry coffee table by planing and scraping, then pulls out his Festool Rotex sander and sands the whole top. Frank says it is to prepare the surface for finish.

I’ve made just four “real” projects in cherry and ash and, with wipe-on film finishes, sanded only between coats. I avoid sandpaper, mostly because of the mess in my garage—it gets everywhere.

I doubt there’s a simple answer to this—but is it species-related, finish-related or just a preference as to whether you sand before applying finish?

Nathan Harold
Pleasanton, California

Nate,

Historical practice goes something like this: Plane until you can’t get the surface any nicer. Scrape any tear-out. Use an abrasive to blend the textures of the two kinds of surfaces and remove any remaining tool marks.

Sometimes you don’t need to scrape or sand because the wood is so well-behaved. Sometimes the type of finish you are using (such as French polish) demands a dead-flat surface that requires sanding.

So it really just depends. Here are some additional thoughts.

1. Abrasives were around before planes (sandstone), so don’t pooh-pooh their effectiveness.

2. Sometimes sanding is needed, especially when you are using modern dye stains. A sanded surface makes the dyes penetrate more evenly in my experience.

3. After you put a film finish on a piece of wood, it’s impossible for most people to tell if the wood was sanded or planed.

4. Planing is faster but requires more skill. Sanding is slower, but it is easy to learn the basics.

So the bottom line for me is this: Plane if you can, sand if you must.

Christopher Schwarz,
contributing editor

Avoiding Amber Waves

I used Zinsser Amber Shellac for an early banjo I made. While it turned out pretty good, I had a lot of trouble. I used the shellac straight out of the can, and it ran and streaked a lot. I am almost finished with a parlor guitar, and I am thinking of using the same shellac. This time, however, I will thin it so as to hopefully avoid most of that.

Should I thin the amber-tone stuff to a one-pound cut? If so, does that mean fill a jar two-thirds full of denatured alcohol and fill the remaining one-third from the shellac can? Should I make a thicker mix for later coats? Also, what type of brushes do you use?

Jason Stamper
Mountain City, Tennessee

Jason,

I think Zinsser comes out of the can at a three-pound cut; one pound is pretty thin, but I wouldn’t make it any thicker for later coats—just add more coats. I’d experiment first with a two-pound (or so) cut (about two-thirds shellac and one-third alcohol).

These days I use a spray system for shellac and almost every finish (except paint)—it’s much closer to foolproof than ragging or brushing.

If I did have to brush shellac, I’d use a natural (ox) bristle.

But for such a lovely and involved item as a guitar, I’d take the time to do a proper French polish. It’s not difficult; it just takes a little time and stick-to-itiveness. PWM

Megan Fitzpatrick, editor

ONLINE EXTRAS

Letters & Comments

At popularwoodworking.com/letters you’ll find reader questions and comments, as well as our editors’ responses.

We want to hear from you.

Popular Woodworking Magazine welcomes comments from readers. Published correspondence may be edited for length or style. All published letters become the property of Popular Woodworking Magazine.

Send your questions and comments via e-mail to popwood@fwmedia.com, or by mail to 8469 Blue Ash Road, Suite 100, Cincinnati, OH 45236.



Highly Recommended

Dental floss (an unwaxed tape variety that doesn’t leave filaments behind but isn’t overly slick) is a cheap and easy-to-find item that belongs in your toolbox.

I use it most often for pulling glue into cracks (say, if I bang together too-tight dovetails and cause a minor split). Pull out a length, coat a bit of it with glue, then work it into the split. Remove the floss and clamp. Floss also comes in handy for cleaning junk out of small drill bits and the lead screws on auger bits.

— Megan Fitzpatrick

POPULAR Woodworking MAGAZINE

Customer Service

How can I contact customer service with questions regarding my subscription, including a lost or damaged issue?

Visit popularwoodworking.com/customerservice. Or write to Popular Woodworking Magazine, P.O. Box 421751, Palm Coast, FL 32142-1751. Or, if you prefer the telephone, call 1-877-860-9140 (U.S. & Canada), 386-246-3369 (International) and a customer service representative will be happy to help you.

When does my subscription expire?

The date of your subscription expiration appears on your magazine mailing label, above your name. The date indicates the last issue in your subscription.

Can I get back issues of Popular Woodworking and Woodworking Magazine?

Back issues are available while supplies last. Visit popularwoodworking.com/backissues. Or if you know the exact month and year of the issue you want, call our customer service department toll-free at 855-840-5118 to order.

What if I want more information about the projects or tools I read about in Popular Woodworking Magazine? For all editorial questions, please write to Popular Woodworking Magazine, 8469 Blue Ash Road, Suite 100, Cincinnati, OH 45236. Or send an e-mail to popwood@fwmedia.com.

Does Popular Woodworking Magazine offer group discounts?

Group discounts are available by special arrangement with the publisher. For more details, send an e-mail to Debbie.Paolello@fwmedia.com or call 513-531-2690 x11296.

Our Privacy Promise to You

We make portions of our customer list available to carefully screened companies that offer products and services we believe you may enjoy. If you do not want to receive offers and/or information, please let us know by contacting us at:

List Manager, F+W Media, Inc.
10151 Carver Road, Suite 200
Blue Ash, OH 45242

Safety Note

Safety is your responsibility. Manufacturers place safety devices on their equipment for a reason. In many photos you see in Popular Woodworking Magazine, these have been removed to provide clarity. In some cases we’ll use an awkward body position so you can better see what’s being demonstrated. Don’t copy us. Think about each procedure you’re going to perform beforehand.

Custom Branding Irons

Distinctive marking for your craft



P: 586.484.7713 • www.branding-irons.biz

CARD #93 or go to PWFREEINFO.COM

If you are in a woodworking business... this could be the most valuable tool in your office™.


Contact us to receive your **FREE** 720 page

Woodworker's Supply Inc.
(Since 1972)

Big Book of Woodworking 2015 catalog

TO ORDER:

- Go to woodworker.com/pw15 or
- Call 800-321-9841 (mention code pw15)



CARD #54 or go to PWFREEINFO.COM

AMAZE YOUR FRIENDS!

SAW LIKE A PRO!
with backsaws by
GRAMERCY TOOLS



toolsforworkingwood.com

Our online catalog features over 4,000 tools & accessories.

CARD #45 or go to PWFREEINFO.COM

How Did We Make the Best Even Better?

It's just what we do...

1.5 / 2 / 3 / 5hp
V-Systems



Most companies wouldn't even consider touching a dust collector as good as our V-System but at Oneida, innovation is our life blood. We re-designed our "Best In Class" V-Systems to be even better. The molded, static conductive, industrial resin cyclones are lighter, more efficient and deliver higher CFM with the same strength and quality Oneida has always been known for. The best just got better.

- All of our systems are ETL certified.
- Most systems have HEPA filtration.
- Complete line of ductwork.
- Ductwork design help available.
- We have systems for every shop.
- American - made quality since 1993.

Clean Air to Vac

Deluxe Dust Deputy®

A great gift for your craftsman!

Pays for itself in replacement filter costs alone!



- Patented design keeps 99% of the dust from reaching your vacuum filter.
- Vacuum doesn't lose suction.
- Retrofits to any shop vacuum.
- Easy to empty dust bucket.

Now Available at these fine retailers.

ACE **WOODCRAFT**
MENARDS
The helpful place. Dedicated to Service & Quality™

Call Today for Information & **FREE** Online Catalog!

1.800.732.4065

www.oneida-air.com



Dust Collection Since 1993.

CARD #35 or go to PWFREEINFO.COM

THE WINNER:

Forstner Bit in a Hand Brace? Sure!



Trying to bore with a Forstner bit using a hand brace is a nearly impossible task. I've come up with a solution that works fast and effortlessly.

Drill a pilot hole to whatever depth you desire, then place the point of the Forstner bit into the hole. The cutting edges of the bit itself will then come into contact with the timber, and you can start boring; within a short amount of time, you'll have successfully bored a hole.

The real beauty is that the pilot hole acts as a depth stop. Once the bit bottoms out to the depth of your pilot hole, it will not bite into the timber; it will just spin in place and stop cutting.

So not only can you bore faster, you can bore to depth without fear of going beyond your "depth stop" pilot hole.

Salko Safic
Pacific Pines,
Gold Coast, Australia



Precise Plane-blade Setting


One way to attack problems with tear-out when handplaning is to set the chip-breaker tight to the edge of the plane blade. Here's a foolproof way to get a precise and repeatable blade setting every time.

Select a feeler gauge with a thickness equal to the distance you want to set the breaker back from the cutting edge – say .005". Tape the feeler gauge to a hard, flat surface.

Touch the back of the iron to the flat surface and against the edge of the feeler gauge. Slide the breaker down the back of the iron until it touches the feeler gauge. (If the iron has a curved cutting edge, apply downward pressure in the center of the iron and the breaker.)

Tighten the cap screw, and you're done.

Rhett Fulkerson
Frankfort, Kentucky



Show, Don't Tell

I worked with a couple a while back who were trying to meet two competing concerns for a custom dining set: They wanted a table large enough for six people, but they wanted it as small as possible.

After they decided on an overall table shape and chairs, I sent them home with six chairs and a cardboard cutout of the smallest six-person table I could recommend (40" x 72"). They wanted a 60"-long table.

I had them invite four of their largest

friends to dinner, then serve them with that template laid atop their existing table and the chairs gathered 'round.

After dinner, they decided a 68"-long table was as small as they could go.

Mark Hicks
Ozark, Missouri

Dodge Marital Discord With an Oil Drain Pan

I've been using my wife's metal pie pans for cleaning table saw and miter saw blades. Besides the fact that the blade's teeth scratch up the inside of the pan, she just doesn't like the idea of baking pies in a pan that was used to clean


cruddy saw blades. I've been banned from the pan!

I never liked the idea of possibly dulling the teeth by banging them around in a metal pan anyway, so I started to think about a substitute. A shallow plastic pan, with a diameter large enough to accommodate 10"-12"

saw blades, would be great. After some thought, I came up with a plastic oil-drain pan from an auto-supply store. And I found such a pan at the local dollar store for...\$1.

Just place the saw blade in the pan, squirt in some liquid dish soap and add enough warm water to cover the blade. Let it soak for a few minutes, then scrub the blade and teeth with a plastic- or brass-bristled brush. The drain pan does the job, and the soft polyethylene surface won't take the edge off the teeth.


John Cusimano
Lansdale, Pennsylvania



A Corker of a Blade Guard

One of my students showed up with all of his knives and awls protected by corks from wine or beer bottles. It seems silly, but cork is the best reusable guard I've found. It doesn't slip off, like plastic protectors. And it makes your sharp tools easy to find in a tool chest.

Christopher Schwarz
Fort Mitchell, Kentucky



Automotive Starting Fluid Makes a Mean Brush Cleaner

To clean polyurethane finishes or oil-based paints from small paintbrushes, such as a hobby or artist's brush with natural bristles, the typical approach is to dispense a tiny amount of mineral spirits or other solvent into a small container, then soak the brush. But there's an easier and more convenient way: Use a spray can of "starting fluid" from an auto-parts store.

Spray the fluid directly on the bristles. As with all flammable solvents, always use in a well-ventilated area and away from open flames. Also, be careful about where you direct the overspray (starter fluid is a solvent after all – it likely contains heptane – and thus can damage some finishes). Then wipe the brush dry with a paper towel.

Repeat this process two or three times or as needed.

The final step is the same as with any solvent: Wash the bristles with soap and water, rinse well and let dry. **PWM**

David Long
Lexington, Kentucky

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

TRICKS ONLINE: We post tricks from the past and film videos of some *Tricks of the Trade* in use in our shop. They're available online, free. Visit popularwoodworking.com/tricks to read and watch.

Our products are available online at:

■ ShopWoodworking.com

Cash and prizes for your tricks and tips!

Each issue we publish woodworking tips from our readers. Next issue's winner receives a \$250 gift certificate from Lee Valley Tools, good for any item in the catalog or on the web site (leevalley.com). (The tools pictured below are for illustration only and are not part of the prize.)

Runners-up each receive a check for \$50 to \$100. When submitting a trick, include your mailing address and phone number. All accepted entries become the property of *Popular Woodworking Magazine*. Send your trick by e-mail to popwoodtricks@fwmedia.com, or mail it to *Tricks of the Trade, Popular Woodworking Magazine*, 8469 Blue Ash Road, Suite 100, Cincinnati, OH 45236.



DEROS Random-orbit Sander

Mirka's compact electric sander performs like an air-powered tool.

I avoid sanding as much as possible – but sometimes it has to be done. Since early 2010, when we got a Mirka CEROS (Compact Electrical Random Orbital Sander) in for pre-release testing, that's been my go-to tool for this dreaded task.

What I've never liked about the CEROS, however, is that it plugs into an external power pack that then plugs into the wall. Yes, the sander outperforms other electric sanders (it looks, feels and performs like an air-powered unit), but coupled with the power pack for which you have to allow room, it's far more cumbersome to move around, there are several connections to check, and it takes more space to store. And it's a bit inconvenient to pack up and transport.

Mirka's new 5" DEROS (Direct Electric Random Orbit Sander), though...I'm wholly impressed. This 4,000-10,000 rpm variable-speed tool replicates all that's praiseworthy about the CEROS, but it plugs directly into a typical household wall outlet. No more external power pack. Plus, the power cord is integrated into the 18' dust-collection hose (a 30' hose is also available), so it never gets in the way.

At just 2.3 pounds on our postal scale, the DEROS weighs less than the Ridgid R2601 electric random-orbit sander (ROS) I bought for use at home (3.4 pounds).

In December, I sanded my butch-



Fast & clean. The Mirka DEROS sander performs like an air-powered tool – and the dust collection is amazing. The damp paper towel at right contains all the residual dust wiped from a 9' butcher-block counter after sanding.

er-block countertops and leveled the walls and ceiling of a room that formerly featured faux Venetian plaster. On two walls and half a ceiling, and on one counter, I used my Ridgid; for the second room and other counter, I used the DEROS. Less weight, coupled with better balance and control because your hand is much closer to the work, makes a huge difference – particularly when sanding overhead and on vertical surfaces (I had a lot of both on the walls).

The tool's height is 3³/₄"; Porter-Cable's 390K low-profile ROS is 4³/₈" in height, which is already 1" or so shorter than other ROS models). And the on/off – the paddle on top – is a lot more convenient than the typical side-mounted switch.

The dust collection difference between the two, both hooked up to the same Festool CT mini vacuum, and with the same sanding discs (Abranet),

was also noticeable; I had far less clean-up on both wood and plaster with the DEROS.

It's also quiet; I didn't have a decibel meter handy at home, but it passed the "cat test" – they didn't run. (The company's literature states the dBs as 71.)

The one sticking point is the price; at almost \$600, this sander is significantly spendier than other consumer electric sanders. But the technology and performance are also significantly better. So while I'm not ready to say goodbye to my Ridgid (I can't bear to bin an adequate tool, particularly one I don't use often), when the time comes for a replacement, I will shell out the extra dough for better performance, better dust collection and ease of use. There is likely a lot more plaster work in my future when I find a new old house to rehab, so it will be worth it.

—Megan Fitzpatrick

CONTINUED ON PAGE 14

DEROS Sander MID550201

Mirka ■ mirka.com/deros or 330-963-6421

Street price ■ from \$595

■ VIDEO Find out more about the DEROS in a free Popular Woodworking video.

Price correct at time of publication.

**WEST PENN
HARDWOODS, INC.**

The Largest Importer
of Exotic Hardwoods
From Pen Blanks to the
Whole Log!

Use Coupon Code: **PW04** to receive **10% OFF** your next order!

We have expanded our inventory of unique
slabs/flitches to include: African Mahogany,
African Teak, Bocote, Granadillo, Guanacaste,
Madre Cacao, Olivewood, Primavera,
Purpleheart, Sapele and Waterfall Bubinga

230 South Clinton Street, Olean New York 14760
Phone: 716-373-6434

Email: support@westpennhardwoods.com

Visit our Website:

www.westpennhardwoods.com



CARD #126 or go to PWFREEINFO.COM

**Maximum Strength
Maximum Control**



Get Control with the Strongest,
Stiffest Fret Saws on Earth
Available in
Titanium or Aluminum

www.knewconcepts.com

CARD #60 or go to PWFREEINFO.COM

**ROUTER
BOSS**

Redefines Woodworking

Only Router Boss can cut all traditional
wood joints without restricting your choice
of bits or spacing of cuts, and safely climb
cut on the edge, face or end of a board.
Its cutting edge technology offers digital
displays, lasers and computer templates.
Cuts can be made in any direction as it
firmly grips the wood you are working.
Router Boss gives you superior control
and design capabilities with less risk.



**Take your
woodworking
to the next
level with
Router Boss!**

See Router Boss in Action
on our website:

chipsfly.com

Or call 513.233.9019

**FREE SHIPPING
IN MARCH***



The Lumber Smith

105 lbs - Stainless & Aluminum

Starting at \$2145⁰⁰

804.577.8613 • lumberSmith.com

*Free shipping of a Lumber Smith Sawmill in the lower 48 states for purchases in March, 2015.
Does not apply to accessories.*

CARD #112 or go to PWFREEINFO.COM

Chairs?
No problem.

Three easy steps to routing
perfect mortise & tenon joints.



SEE VIDEO

leighjigs.com

800-663-8932

LEIGH

LEIGH MORTISE & TENON JIGS

Easy Wood Tools 1/8" 'Easy Parter' Parting Tool

Since my first experience with Easy Wood tools in 2011, I've been a fan. Thanks to the tools' long-lasting carbide inserts, I can focus on the shapes I want to produce instead of heading to the grinder or tweaking the lathe's tool rest.

The three basic tools in the Easy Wood catalog – the rougher, finisher and detailer – do about 95 percent of the shapes a furniture maker could want when working between centers.

But the one tool that was missing from the line-up was a parting tool.

Easy Wood 1/8" Parting Tool

Easy Wood ■ easywoodtools.com or 866-963-0294

Street price ■ from \$120

■ **BLOG** Read more about Easy Wood tools and the company's origins.

Price correct at time of publication.

Easy Wood has remedied this with a new 1/8" parting tool that makes fine details as small as 1/8" wide that were impossible with the basic set.

As with the other Easy Wood tools, the Easy Parter has a replaceable carbide tooth. But unlike the company's other tools, it isn't changed with a screwdriver. Instead, you use a key (included) that slightly pries open the tool's jaws, allowing the tooth to drop out. Then you put in a new tooth and release the key. It takes 20 seconds.

I have found the Easy Wood carbide inserts to be incredibly long-lasting. If I am careful, I can turn the parts for as many as 10 Roorkee chairs before requiring a fresh edge.

The Easy Parter works just like all the other Easy Wood tools. You hold



the handle parallel to the floor and gently push the tool into the work. It cuts smoothly and quickly.

My only quibble is that the cutting edge of the Easy Parter is about 3/16" higher than the cutting edge on my other Easy Wood tools, so I have to lower my tool rest to use the tool. But that's a small price to pay for avoiding the grinder.

— Christopher Schwarz

Bosch 'Power Ready' Wireless Charging System

Although wireless charging is nothing new (it's been around for years for home and mobile phones), the Power Ready system from Bosch is a first in the tool sector.

As of this writing, the system includes only the WCBAT612 18-volt thin-pack 2Ah battery (\$89), which is backward-compatible with all of the company's 18V lithium-ion tools. But a press release states that this spring Bosch will introduce fat-pack 4Ah batteries to the wireless lineup. (Both will also charge on a traditional charger.)

I was skeptical at first, because you do, after all, still have to find a plug for

the charger (WC18C; \$59) and remember to put the tool atop it. But I used the system in the shop for a few weeks, and (after I trained myself to put it back where it belongs) it really is faster and more convenient than switching out the batteries...and hoping your backup battery is charged.

A benchtop charger frame (WC18F; \$12) keeps the battery properly aligned to charge, but if you don't use the frame (I did not) pay attention to the light display; green means it's working – and without the frame, it's a little fussy to align things correctly. There's also a holster-style frame (WC18H01; \$49) available to mount the charger and a drill on the wall (or in a work truck).

It takes just under an hour to reach a full charge from empty, and about 30 minutes to reach an 80-percent charge – but if you keep the tool where it belongs when it's not in use, that's never an issue. And of course it stops charging when the battery is full.



The inductive charging (an alternating magnetic field) works only when a compatible battery is on the pad. And the pad won't function if it identifies a foreign object, such as a screw or metal shavings. **PWM**

— MF

Wireless Charging System

Bosch ■ bosch.com

Street price ■ from \$138 (for the battery & charger)

■ **BLOG** Read more about this system and see it in action.

Price correct at time of publication.

UNIQUE SOLUTIONS



Other Products We Offer

- 6-mil Poly Bags
- Quick Release Hose Clamps
- Self Adhesive Foam Gasket
- Custom Transfer Sleeves
- Cartridge Filters



Our Dust Bags Feature

- Optimum Performance
- 1-Micron Filtration
- Custom Designs
- Cleaner Air
- Longer Life

Free Design Assistance for All Custom Made Dust Bags

AMERICAN FABRIC FILTER CO.

www.americanfabricfilter.com - Phone: 800-367-3591 - Info@americanfabricfilter.com

CARD #66 or go to PWFREEINFO.COM

Big News for the Kitchen

Massive Island Leg Collection

6-8" Wide Island Legs

Over 20 Stock Wood Types

Classic & Contemporary Styles

Same Day Shipping Available



Request a Free Catalog

1.866.963.5576

www.customlegs.com

CARD #36 or go to PWFREEINFO.COM

KLINGSPOR'S WOODWORKING SHOP

"Quality Tools and Supplies for the Woodworker"

Woodworker's #1 Online Source for Klingspor Abrasives

Shop Our New & Improved Website
\$7.99 FLAT RATE SHIPPING ALWAYS!
www.woodworkingshop.com • 800-228-0000

CARD #89 or go to PWFREEINFO.COM

BESSEY® K Body® REVO™



Powerful parallel clamping at its best

- **Powerful parallel jaws:** 90° jaws with up to 1500 lbs of clamping force and 3 3/4" throat depth
- **Quality construction:** German engineering, German steel, assembled in USA facilities
- **Large ergonomic 2K composite handle:** High quality for greater comfort and better grip
- **Removable end-clip** to easily switch to a spreader
- **Removable jaw pads** for easy clean up
- **Choices / options:** Available in 9 sizes from 12" to 98".

BESSEY®. Simply better.



UP TO
1500 lbs
CLAMPING FORCE

3 3/4"
THROAT DEPTH

90°
PRECISION
CLAMPING



www.besseytools.com

CARD #101 or go to PWFREEINFO.COM

Killer Wood

Don't let fabulous figure overshadow your design elements.

Much has been written about how Michelangelo, the great artist and sculptor, spent years of his life in the Carrara, Italy, marble quarries. He sought out promising stone and often took part in the whole process, from the initial sectioning of blocks from the mountainside to the actual supervision of transporting stone to his studio in Florence.

One note of interest: The master sculptor had the enormous blocks roughed down close to their finished forms while still on the quarry floor. He provided drawings to guide the rough stone cutters and in this way minimized the cost to transport the massive stones.

Some things never change. Outstanding stone or wood is always in short supply and expensive. Yet there are hardly words to describe the bliss as a rough chunk of figured grain shimmers at first light.

Our ancestors long ago learned how to exploit the useful properties of wood. They knew that the toughness of elm made a wagon wheel hub that could take a beating, and that the elasticity of English yew could lend its power to an archer's bow.

Yet aside from its countless utilitarian qualities, wood occasionally shows flashes of glory. Like our ancestors, we can't help but be dazzled by the shimmering grain and tangled brushstrokes painted by nature in the face of a board.

Figure Can't Trump Form

There are no magical design formulas that come into play before we plunge a saw into some ridiculous claro walnut, but it's obvious the stakes are higher.

The good stuff, what the lumbermen call their "private stock," is rare and costly. That alone gives pause. But for me it's the thought that nature offers



Responsible use. Rich claro walnut (top) and figured mahogany deserve our finest design efforts.

up a special gift, created by storms, hardship, frigid winters, blistering droughts and a bit of mystery. I don't take that lightly, and I always desire to make something worthy of the special material.

It's also important to note that, although dramatic figured wood can make a profound statement, it cannot make up for a poor underlying design. Ask yourself before committing that special wood: Will this design hold up even if it were made with tulip poplar or construction pine?

That's actually a good question to ask before applying carving, marquetry or outstanding wood to any project. If the underlying bones are good, that blistered maple may transform it into something great. If the form itself is lacking, the best wood in the world will not make up for it.

Don't Fight It

I've always had a soft spot for figured maple and early on was eager to see how other woodworkers past and present used it to maximum effect. One thing I noted is that it's very rare for it to show up in heavily carved sculptural work such as ball-and-claw feet.

I posed the question to a few experienced carvers and always heard the same answer: Figured wood is troublesome to carve and therefore one to avoid. No doubt that's one of the primary reasons it's seldom carved.

Yet, one important maxim in design is that, any time we pair two different things, the goal is always that each will complement and bring out the best in the other. Together, the pairing results in something more than just the sum of the two.

Plunging a gouge through the sur-

CONTINUED ON PAGE 18

From Lignomat
Pin and Pinless

Moisture Meters

Avoid
Shrinking
Warping
Cracking
Cupping

Buy Quality, Accuracy, Reliability
and Professional Customer Service.



2-Year
Warranty!

??? Check out the info Web-site
www.wood-moisture.com

800-227-2105
Call today for more info.
www.Lignomat.com

CARD #124 or go to PWFREEINFO.COM

Lie-Nielsen
TOOLWORKS[®]
INC.



Made in Maine
1-800-327-2520
WWW.LIE-NIELSEN.COM

TAPERED
DOVETAIL SAW

CARD #29 or go to PWFREEINFO.COM

STEVE WALL LUMBER CO.

Quality Hardwoods and Plywood For The
Craftsmen and Educational Institutions

Alder	4/4	Select	3.30
Ash	4/4	Select	2.60
Basswood	4/4	Select	1.95
Birch	4/4	Select	3.50
Butternut	4/4	1C	3.25
Cedar	4/4	1C+Btr.	2.00
Cherry	4/4	Select	4.90
Cypress	4/4	Select	2.75
Hickory - Pecan	4/4	Select	3.00
Mahogany (Genuine)	4/4	Select	5.10
Maple (Hard)	4/4	Select	3.65
Maple (Soft)	4/4	Select	2.60
Oak (Red)	4/4	Select	2.80
Oak (White)	4/4	QS	2.90
Poplar	4/4	Select	1.80
Walnut	4/4	Select	5.75
White Pine (Soft)	4/4	F.G.	1.40
Yellow Pine (Soft)	4/4	Clear	2.20

Above prices are for 100' quantities of kiln dried rough lumber sold by the Bd. Ft. FOB Mayodan, NC. Call for quantity discounts. Other sizes and grades available.

UPS	\$ 90.00
Specials	\$101.00
	\$ 91.00
	\$115.00
	\$ 98.00
	\$ 85.00
	\$129.00
	\$ 97.00
	\$108.00
	\$122.00
	\$116.00
	\$ 95.00
	\$105.00
	\$105.00
	\$ 85.00
	\$125.00
	\$ 78.00
	\$ 90.00

SEE OUR
CATALOG ON
THE WEB!

Above prices are 20 bd. ft. bundles of clear kiln dried lumber 3"-10" wide • 3'-5' long (Random widths & lengths) Surfaced 2 sides or rough. Delivered Ground prepaid in the Continental U.S.

OLIVER MACHINERY DEALER

HARDWOOD PLYWOOD

CUSTOM RAISED PANEL DOORS

CUSTOM PLANK HRDWD FLOORING

THIN CRAFTWOOD

EXOTIC LUMBER

STEVE H. WALL
LUMBER CO.

BOX 287
MAYODAN, N.C. 27027
336-427-0637
1-800-633-4062
FAX 336-427-7588
Email: woodsales@walllumber.com
Website: www.walllumber.com

Send \$1.00 For Lumber Catalog
Prices Subject to Change Without Notice

CARD #47 or go to PWFREEINFO.COM




Turn a rough driveway
into a SMOOTH RIDE.

The DR[®] POWER GRADER tows
behind your ATV or lawn tractor.



Finally an easy way
to do it yourself.

DRpowergrader.com



RESURFACE YOUR
DRIVEWAY without
bringing in new material.
MINING GRADE CARBIDE-
TIPPED TEETH shave down
bumps, washboard and
other high spots.
REAR LEVELING BLADE
with patented geometry, fills
in potholes, ruts, and wash-
outs with loosened material.
POWERED ACTUATOR
raises and lowers the
scarifying teeth to suit the
conditions at hand.

86091X © 2014

Stump Removal FAST & EASY!



- ✓ EXPAND lawn areas.
- ✓ OPEN UP fields and meadows.
- ✓ BLAZE new trails.
- ✓ REMOVE mowing hazards.

Now Towable!

The DR[®] STUMP GRINDER uses carbide-tipped cutting teeth that take over 360 "bites" per second, pulverizing stumps into a pile of woodchips. Quickly and easily, you can grind any size tree stump below ground level. Gone forever!



DRstumpgrinder.com

86092X © 2015

**FREE
SHIPPING**
SOME LIMITATIONS APPLY.

Try a DR[®] at Home
for 6 Months!
Call for details.

Call for a FREE DVD and Catalog!

Includes product specifications and factory-direct offers.

TOLL FREE **877-200-6958**



face of a figured wood often kills the striking grain. Instead of the dramatic tiger stripes dancing across the surface of a flat board, it takes on a mushy look when sculpted into a curved or irregular surface.

Worse, in the random spots where the figure shows through the surface, it visually fights with the carving itself. It defeats the whole purpose, almost like two trumpets playing different music with a different beat.

The same can be said for mouldings. Although it's tempting to try to add some pop to mouldings by using figured wood, we have to understand what we are trying to accomplish. The primary purpose of mouldings is to add depth by producing strong bands of light and shadow.


Figured stock, aside from its difficult working properties, will only detract from the very effect we are trying to accomplish. The shimmering grain actually takes away from the sense of depth we are trying to achieve through shadow lines.

Make Beauty Stand Out


Carvings and mouldings both hint at something important about using dramatic wood. Less is more.



Indistinct shadows. Mouldings are nothing more than bands of light and shadow. Figured grain actually muddies the shadow lines.



The right frame. A plain or figured door frame – which takes away from the dramatic grain in the panel?



Sawn revelations.

Bird's-eye black walnut anyone? Nature never ceases to unveil surprises.



Hidden treasure.

How about a bubbly? The boiling surface of this figured maple shimmers even in the rough-sawn state.

That amazing curly koa will have a much more dramatic effect if we frame it in a way that allows the beauty to stand out. That means we use restraint in our selection of wood to frame it. It's best to frame in either plain wood or, at most, a contrasting wood tone that complements the striking panel.

As tempting as it is to construct door frames and banding from wild grain, if we want to showcase the dramatic, it's best to play it off something understated.

We underestimate the craft tradition when we think the period woodworkers opted for straight-grained woods in door frames simply because it was easier to work with hand tools. Discriminating builders know that the frame is not the star. It's the panel inside the frame. Let the door panels sing by letting the backup singers do just that – play backup.

It seems a bit counterintuitive, but in the end this will make that special wood shine brightly and take your work to another level.

Many Thanks to the Sawmill

Finally, it's important to note that, although rare and beautiful wood is expensive, it's not the place to scrimp.

When I look back over furniture

I've built, I never regret spending more for that burl wood or that really dense walnut. If you are lucky enough to find a lumberyard that carries great wood, consider yourself fortunate.

The better ones, such as Horizon Wood Products, not only carry amazing wood but also understand the needs of furniture makers.

My only regrets are that I didn't buy more, not less. **PWM**

George is the author of two design DVDs (Lie-Nielsen Toolworks) and writer of the Design Matters blog.

ONLINE EXTRAS

For links to all these online extras, go to:

■ popularwoodworking.com/apr15

BLOG: Read more from George R. Walker on his *Design Matters* blog.

IN OUR STORE: "Unlocking the Secrets of Traditional Design" and "Unlocking the Secrets of Traditional Design: Mouldings," DVDs by George R. Walker.

Our products are available online at:

■ ShopWoodworking.com

About This Column



Design Matters dives into the basics of proportions, forms, contrast and composition to give you the skill to tackle furniture design challenges with confidence.

free WEBTV for woodworkers.



coming this season

Christopher Schwarz • Mary May • Glen Huey
George Walker • Don Williams • Scott Phillips



www.thehighlandwoodworker.com

CARD #91 or go to PWFREEINFO.COM

Forrest Sharpening

Helps Prevent Bad Cuts Like These



Abrasion, pitch buildup, micro chipping and poor sharpening jeopardize the life and performance of even the finest carbide-tipped blades and dado sets. Our *expert factory sharpening* will help protect your investment. We handle *all types and makes of blades*. Typical turnaround is just 4 to 5 days.

We've been the leader for over 60 years, so contact us today.

FORREST

The First Choice of Serious Woodworkers Since 1946

www.ForrestBlades.com
1-800-733-7111

(In NJ, call 973-473-5236)

© 2015 Forrest Manufacturing Code PW

CARD #13 or go to PWFREEINFO.COM

Popular Woodworking Presents *Woodturning with Tim Yoder*


— Tune in now. Shows airing each Saturday! —

Popular Woodworking Magazine has teamed up with well-known PBS star Tim Yoder to launch a new online video show, filled with expert and friendly advice that will teach you how to become a better woodturner.

In each 30-minute episode, Tim takes you through the process of making beautiful woodturning projects. Plus, you'll learn his favorite turning tips and techniques, and he'll offer reviews of the latest lathe tools, chucks and accessories to help you determine the best products to buy.

Visit www.popularwoodturning.com every Saturday for the latest episode of *Woodturning with Tim Yoder*.

This show is brought to you by: Easy Wood Tools, Robust Lathes, Titebond Glue, Thompson Lathe Tools, Woodworkers Emporium, Rikon Power Tools, and American Association of Woodturners.



Tim Yoder, who starred in the Emmy Award-winning show *Woodturning Workshop* on PBS, has teamed up with *Popular Woodworking Magazine* to launch a new turning show.

World's 1st Self-Feeding Chipper For Homeowners!



Just load a DR® RAPID-FEED™ CHIPPER, step back, and watch it chew up 5½" thick branches!

SELF-FEEDING saves time and energy. Most branches can be dropped into the hopper and will self-feed, instead of you having to force-feed them.

TOP-DISCHARGING is standard on all models, for easily collecting discharged chips in a container or cart.

PRO-SPEC™ CHIPPER KNIFE is made of edge-holding, forged alloy tool steel.



TRACTOR OWNERS
3-Point Hitch models too.

FREE SHIPPING 6 MONTH TRIAL!

TOLL-FREE
877-200-6958
DRchipper.com



86093X © 2015

Woodworking in America

SEPTEMBER 25-27, 2015
KANSAS CITY, MO
SHERATON KANSAS CITY
AT CROWN CENTER

KANSAS CITY HERE WE COME!

Popular Woodworking Magazine is bringing the ultimate woodworking weekend to Kansas City!

Save the date for your woodworking getaway, featuring:

- Dynamic woodworking education from Roy Underhill, Christopher Schwarz, Alf Sharp, Tom Fidgen and many more masters of the craft
- A Marketplace packed with the best hand-tool makers, power-tool vendors and woodworking suppliers—all under one roof
- Three days of exciting activities making for one unforgettable woodworking weekend

LEARN MORE: WoodworkingInAmerica.com



SPONSORS:

POPULAR
Woodworking
MAGAZINE



@WIAConference



WOODWORKINGINAMERICA



This \$9,500 Workshop Could Be Yours!

ENTER ONLINE TODAY

for your chance to **WIN A
COMPLETE SHOP** that
features **ALL** you
see here!

ENTRY DEADLINE:
Midnight, Eastern
Daylight Time,
May 31, 2015



10" Proshop Table Saw
JPS-10



16" Planer
JWP-16OS

JET



Lathe
JWL-1015



6" Jointer
JJ-6CSDX



1 1/2-HP Dust Collector
DC-1100VX-CK



14" Band Saw
JWBS-14SF



Saw Gauge
SG-WP



Coping Sled
COPELED1



Router Table
PRP-4-V2420

Woodpeckers®



Two Variable Pressure
Featherboards
VPFB



24-4" Light Duty
Step-Over Clamps
LMU2.004



K-Body® Revo™
Framing Kit
KRK2450



6 - EZS 12" Clamps
EVS30-8



K-Body® Revo™
Extender Kit
KRK2450



Drill Press Table
WDPDPACK2

ENTER NOW!

Complete prizes and contest rules
are also available at www.popwood.com/winshop.

popularwoodworking.com/winshop

Popular Woodworking Magazine's "WORKSHOP MAKEOVER GIVEAWAY" SWEEP-STAKES: These are only abbreviated rules. The "Workshop Makeover Giveaway" Sweepstakes is subject to Official Rules available during promotion period (Jan. 1, 2015 - May 31, 2015) at www.popwood.com/winshop. See Official Rules for complete entry details and prize descriptions. NO PURCHASE OR SUBSCRIPTION NECESSARY TO ENTER OR WIN. Must be a legal resident of the U.S. or Canada (excluding Quebec) who has reached the age of majority in the participant's jurisdiction of residence to enter. One Grand Prize—Woodworker's Home Workshop valued at US\$9,500. Odds of winning depend on number of entries. Void in Quebec and where prohibited. Sponsor: F+W, A Content + eCommerce Company, 10151 Carver Rd., Suite 200, Blue Ash, OH 45242 USA.

The **WORKSHOP MAKEOVER
GIVEAWAY** is sponsored by:

JET



Woodpeckers®

POPULAR
Woodworking
MAGAZINE

Ruhlmann Tabouret

BY MARIO RODRIGUEZ



Create sultry sophistication with Art Deco details.

Émile-Jacques Ruhlmann (1879-1933) is considered by craftspeople, collectors and designers to be the premier Art Deco furniture maker; he was called “Art Deco’s greatest artist” by *The New York Times* in 2009. All the fuss is for good reason.

This French designer’s work is characterized by the skillful use of luxurious and exotic materials, including ebony, kingwood, ivory, amaranth, Indian rosewood, sharkskin and tortoiseshell. What really set his work apart was how he perfected a purity of line – lithe sinuous curves melding perfectly with sharp, disciplined and crisp rectangles and straight edges.

Ruhlmann insisted on uncompromising quality, and as a result, his pieces consistently lost money, sometimes as much as 20 to 30 percent. For example, it typically took more than 50 hours to create a single leg for a piece. The exquisite workmanship invested into his pieces is immediately obvious to any viewer.

My original design is strongly influenced by Ruhlmann’s collective work and employs a number of details he often used on his amazing furniture. These include the inlaid dot border, contrasting accents, vertically oriented veneer work and slender tapering legs on this piece.

The design is called a tabouret, or work table. Set alongside a desk or drawing board, it would store and organize frequently used tools and materials. But its small size (about 19" wide x 15" deep x 31" high) makes it a piece that can be placed anywhere – in an entryway, at the end of a sofa or next to a bed.

Carcase & Web Frames

The carcase sides and back are made of $\frac{3}{4}$ " shop-grade plywood. After cutting the parts to size, I cut $\frac{1}{2}$ "-deep x $\frac{3}{4}$ "-wide rabbets on the back edges of



Solid. Web frames add rigidity to the case and provide surfaces on which the drawers ride. They are housed in $\frac{1}{2}$ "-wide dados in the case sides.



Stubby but strong (enough). Stub tenons are a quick and sturdy solution for frames that don’t support a lot of weight.



Innards first. The carcase is assembled around the web frames, then the back drops into rabbets in the sides.



the side panels to receive the $\frac{3}{4}$ "-thick back, and across the top ends of the side panels for the upper drawer web frame. Next, I cut $\frac{3}{16}$ "-deep x $\frac{1}{2}$ "-wide dados into the sides for the other drawer web frames.

The frames are made of $\frac{1}{2}$ " poplar and are joined with stub tenons set into a lengthwise groove. Once glued up, they are cut square and to final size. And because the $\frac{3}{4}$ " plywood cabinet sides and back are assembled around these three poplar frames, they must be perfectly square and dead flat.


In addition to holding the sides and back of the carcase together, the frames support and guide the smooth operation of the two dovetailed drawers.

Top it Off



For the top’s substrate, I used $\frac{1}{2}$ "-thick birch plywood.

I’m always aware of how delicate and vulnerable a veneered surface is

and that any light blow could damage the surface and reveal the substrate below and destroy the illusion. So to provide more protection to the edge, I laminated $\frac{1}{16}$ " shop-sawn cross-grain mahogany veneer to a foundation strip of $\frac{1}{16}$ " long-grain veneer.



Composite edging. To add some strength to the top’s edges, I laminate the cross-grain veneer to a strip of long-grain veneer.



This makes handling the cross-grain banding easier and also provides critical thickness to the edge as protection against future accidents (as well as against sanding through the veneer during construction).

Glue the edging and hold it in place with luthier's tape. After it's dry, plane and sand the edging flush with the top's surface.

Bookmatched Center Field

After pressing the bookmatched leaves flat, shoot the edges with a block plane to ensure they are straight and matched, and tape them together. Glue them to the substrate panel using cold fish glue; set the work in a giant manual screw press overnight. Then carefully trim the veneer 1 5/8 inches back from the panel edges.

I cut the cross-grain borders 1 3/4 inches wide and pre-cut the miters for a precise fit at the corners. The extra 1/8 inch in width allows me to make last-minute



Sticky solution. After applying glue to the edge, hold it in place with luthier's tape until the glue sets.

adjustments necessary for perfect, tight-fitting miters.

Glue down the border, one piece at a time, using yellow glue and clamping cauls (cover the cauls with any non-stick tape). As I unclamp one segment, I set the next in place, taping across the miters to ensure the joint won't open up later or shift while it's clamped. After




Center field. After the glue sets up overnight in the press, trim the edges of the field 1 5/8 inches back from the substrate's edges.


just a couple of hours of drying time, trim everything flush using a sharp veneer saw. Remember how the grain of the overhanging veneer is oriented and trim it with great care.

String the Panel

I use a Dremel with a 1/16 inch milling bit, attached to a router base, to cut a 1/8 inch-deep



ELEVATION



PLAN SECTION

little “pop” is a Ruhlmann trademark.

These $\frac{1}{8}$ "-diameter dots are cut using a punch made from a $2\frac{1}{2}$ "-long piece of $\frac{1}{8}$ " inside-diameter stainless steel tubing with “saw teeth” cut into one end. Use a 4" XX tapered slim saw file to cut the teeth and to slightly taper the outside diameter.

With the punch chucked into a drill press, lower it slowly (and at a slow speed) into a slice of $\frac{3}{16}$ "-thick holly. After punching out three dots, remove the tube from the drill press and push out the dots before proceeding. Attempting more dots at one time clogs the tubing and crushes or “burns” the dots. Any damaged or discolored dots will show badly, so cut extras and discard those that are less than perfect. You’ll need 80 good ones...and a few extras for insurance.



Straight & true. To cut grooves for the stringing, I use a Dremel in a router base. Notice the clamped straightedge that guides the tool.

$\frac{1}{16}$ "-wide channel for the $\frac{1}{16}$ " holly stringing that is installed all around the center bookmatched panel. (Clamp a straightedge to the top to guide the router base.)

Using a thin-kerf 10" table saw blade and a zero-clearance insert, carefully rip the $\frac{1}{16}$ "-thick stringing; then use the band saw to rip those wider strips



Get into the groove. After mitering the corners, glue the holly inlay strips in place.

into $\frac{1}{4}$ " stringing material.

After mitering the ends with a chisel and a miter block, I fit the stringing into the grooves, then glue it in place with the rough edge up.

Later, it’s planed and sanded flush (when you do that, be careful not to cut through the veneer).

Dotted Edge

A bright staccato band of dots that neatly punctuates the slender top to give it a



Dots. You’ll need 80 holly dots (plus a few extras for insurance). Note the “saw teeth” on the punch.

Ruhlmann Tabouret

NO.	ITEM	DIMENSIONS (INCHES)			MATERIAL	COMMENTS
		T	W	L		
❑ 1	Top	1/2	14 1/8	17 1/8	Plywood	Veneer*
❑ 2	Sides	3/4	11 1/2	14	Plywood	Veneer after assembly*
❑ 1	Back	3/4	11 1/2	17 3/8	Plywood	Veneer after assembly*
❑ 6	Web frame rails	1/2	1 7/8	10 1/2	Poplar	
❑ 6	Web frame stiles	1/2	1 7/8	16 3/4	Poplar	
❑ 1	Face frame rail	3/4	1 1/8	15 5/8	Mahogany	Veneer after assembly*
❑ 2	Face frame stiles	3/4	1 1/2	11 1/2	Mahogany	Veneer after assembly*
❑ 4	Legs	1 1/2	1 1/2	21	Mahogany	Oversized for turning*
❑ 4	Feet	1 1/4	1 1/4	4 1/2	Holly	
❑ 2	Drawer fronts	3/4	4 3/4	14 7/8	Mahogany	Veneer*
❑ 4	Drawer sides	5/16	4 1/4	13 1/2	Spruce	
❑ 2	Drawer backs	1/2	3 3/4	14 7/8	Spruce	
❑ 2	Drawer bottoms	3/16	13 3/8	14 1/2	Spruce	
❑ 1	Staging panel	1/2	12 1/2	13 1/2	Spruce	**
❑ 2	Breadboard ends	1/2	1 5/8	13 1/2	Spruce	
❑ 1	Staging panel front	3/4	7/8	14 7/8	Mahogany	Veneer*
❑ 4	Drawer guides	7/8	7/8	11	Maple	
❑ 2	Panel guides	7/8	1 1/4	13 3/4	Maple	
❑ 6	Knobs	1 1/4	1 1/4	2	Holly	
❑ 2	Leg-dot balls	5/8	5/8	1 1/2	Holly	

*Veneer: Crotch mahogany for center field, straight-grained mahogany for the balance, plus holly stringing for the top. **Includes stub tenon both ends



Tape in place. Lay out the dot locations on a piece of tape, bringing the lines to the table edge. A simple jig helps to align your drill bit and keep it straight; a stop-block on the bit keeps you from drilling too deep.



Dotted line. Use a syringe to inject glue into the holes, then insert the dots all along the edges. When the glue is dry, file the dots flush, then sand.

To position and drill the holes into the edge of the top, make a simple drilling jig (see image below). Lay out the exact position of each dot on strips of tape laid onto the top, then clamp the jig to the top, drill a hole, and move the jig to your next mark.

Inject a small amount of glue into each hole (I use a Monoject #412 plastic syringe) and gently tap the dots into place, leaving each slightly proud.

After the glue dries, work each dot flush using a detail file, then sand the entire edge smooth with #220-grit sandpaper.

U-shaped Face Frame

I attached an open U-shaped face frame to the cabinet to strengthen the carcass. The frame also visually alters the piece, giving the cabinet a more tailored and formal look, and it reduces the drawer opening.

The frame is made up of three mahogany pieces joined with stub-tenon and open-mortise joinery, with the grain running in the conventional direction.

The pieces are veneered with the same mahogany veneer that covers the carcass (see below) to maintain a neat and uniform appearance. The grain of the veneer on the face frame rail is oriented vertically. Because of the narrow size, I veneered the frame-face parts using yellow glue and clamping cauls.

Once the face frame parts are veneered and the joinery is complete, glue up the frame. (I used a spacer along the open bottom of the frame to maintain critical dimensions and to ensure squareness.)

Veneer the Carcase

For the plywood carcase, I chose straight-grained mahogany for its warm, even color and absence of fig-

"The man who has had the greatest influence on designer-craftsmen of furniture in the last 100 years is undoubtedly Émile-Jacques Ruhlmann."

—Silas Kopf,
from "A Marquetry Odyssey"



Face front. The face frame is joined with open mortise-and-tenon (stub tenon) joints; make sure everything is square before you glue up.



Hot hide. The carcass is veneered in the traditional manner, using hot hide glue and a veneer hammer. It's not difficult, but you must work quickly.

ure. Because the case was already assembled, I employed the traditional method of using hot hide glue and a veneer hammer to lay down the veneer.

After brushing warm glue onto the cabinet, place the veneer face down onto the wet glue and apply glue to the backside of the veneer. While it's still wet (and warm), flip the veneer face up and quickly began to press it down with the hammer, squeezing out the excess as you carefully work toward the edges before the glue cools.

After thoroughly pressing down the veneer, I check for any stubborn, unglued edges and bubbles. These can be reheated and eliminated with the ap-

plication of more glue (or heat from an iron) and additional focused pressure until a good bond is achieved. Later, trim the excess with a veneer saw, then plane and scrape the seams smooth before sanding with #220 grit. Add cross-grain veneer to the reveal on the carcass top.

Time for Shapely Legs

I mill my leg stock $1\frac{1}{2}$ " square x 21" long, then cut out a $\frac{3}{4}$ " x $5\frac{1}{4}$ " section at the top of each leg. This cut-out section is replaced with a piece of poplar glued in with a slip of heavy brown paper placed between the poplar and the leg blank. This allows easy removal of the

poplar once the leg is turned.

Next, turn a $\frac{1}{2}$ "-diameter x 1"-long tenon on the bottom of each leg.

For the feet, I prep $1\frac{1}{4}$ " x $1\frac{1}{4}$ " x $4\frac{1}{2}$ " holly blanks, then drill a $\frac{1}{2}$ "-diameter hole into one end and glue them to the tenons on the bottom of the mahogany leg blanks.


Holly is a hard, tight-grained wood that can be turned to a smooth, ivory-like surface. It is the perfect choice for the feet, knobs and other light-colored accents on this piece.

I describe the leg as a "torpedo" shape, tapering to $\frac{1}{2}$ " at the top and $\frac{3}{4}$ " at the foot, with a $1\frac{3}{8}$ " swell at the thickest point.

After turning the legs to a rough shape with a roughing gouge, I clean and smooth the taper starting with my Ashley Isles "3-1" gouge (Item #IT-MARIO125 at Tools for Working Wood), then switch to a $1\frac{1}{2}$ " skew gouge. I finish up with a block plane.



Leg prep. Before turning the legs, cut out a $\frac{3}{4}$ " x $5\frac{1}{4}$ " section from the mahogany and glue in a piece of poplar, with heavy brown paper between the two species.



The drill. Prep, then drill the holly foot blanks to slip over the mahogany leg tenons.



Foot joint. Use a small block plane to smooth the transition from holly to mahogany (mine is a Lie-Nielsen No. 102).

After turning the legs to their final shape and removing them from the lathe, remove the glued-on poplar section by gently guiding a chisel into the seam between the two woods. This leaves a clean-cut ledge on the mahogany leg, which will eventually fit against the side of the carcass.

Staging Panel & Drawers

The slender panel that slides out from beneath the drawers at the bottom of the carcass is used to briefly support, display or organize tools and materials.

I made up a 1/2"-thick panel with breadboard ends and joined the front of the panel to a strip of mahogany (that will line up with the drawer fronts) with a short, continuous tenon. This strip is veneered with the same vertical-grain mahogany as the drawer fronts and face frame for a pleasing waterfall effect.

The staging panel hangs in a pair of U-shaped guides, which are screwed to the underside of the bottom web frame. By screwing the guides in place, I can adjust their positions to provide smooth and easy travel for the staging panel.



Staging strip. The front of the staging panel is attached with a stub tenon that stops just short of either end.



"U" for underhung? The staging panel rides in U-shaped guides attached to the underside of the bottom drawer's web frame.

SUPPLIES

Stewart-MacDonald
stewmac.com or 800-848-2273

1 ■ Binding tape
#0677, \$4.89

1 ■ Router Base
#5260, \$53.65

Prices correct at time of publication.

I cut the drawer fronts to their exact size and veneer the fronts with vertical-grain mahogany. As I did with the carcass face frame, I veneered the fronts with fish glue in a cold press.

The drawer sides, backs and bottoms are made of quartersawn sitka spruce (leftovers from a guitar maker). This stuff has a beautiful, straight grain and a creamy color well-suited to this piece. It's also surprisingly strong, enabling me to mill the stock down to 5/16" for the sides. The backs are 1/2"-thick; the bottoms are 3/16" thick.

The drawer sides are joined to the fronts with hand-cut half-blind dovetails, and to the back with through-dovetails.

The drawer bottoms are inserted with the grain running side-to-side; that way any wood movement is directed toward the back of the drawer. To accommodate that movement, I insert a screw and washer through open slots cut into the back of the drawer bottom.

I build drawer boxes slightly larger than the opening, which allows me to plane them down for a perfect fit, one stroke at a time.

Before fitting the drawers, glue wood drawer guides onto the drawer webs. These guides take up the space between the carcass interior and the face frame. By handplaning them, I can tweak them to provide smooth travel for the drawer boxes and create even spacing of the drawer fronts.

Turn the Knobs

For the holly knobs, prep several blanks to 1 1/4" square by about 2" long.

Once they are turned round to 3/4" diameter, I put them in a collet chuck. This allows me to turn a tenon (3/8"-diameter) and knob without having to remove and re-chuck the blank.



Half-blind. At the front, the drawers are joined with half-blind dovetails (through-dovetails are used at the back).



Allowance. Hold the drawer bottom in place with a washer and screw in a slot to allow for seasonal wood movement.



Guides. Drawer guides should be fairly tight to the drawer sides to keep things from binding. Fit them by hand for smooth travel.

Once the shape is complete, I sand and burnish each knob to a super-smooth finish while it's spinning on the lathe.

The tenons are inserted in holes drilled on the drawer and staging panel fronts. Turn the tenons for a tight fit so they won't loosen over time. Setting them is a small challenge. To embed the knobs gently, I use a wooden handscrew to press them into place (rather than knocking the crown).

Leg Punctuation

At the top of the legs are 1/2"-diameter round dots. As with the knobs, I turn these on the collet chuck, leaving a generous tenon.

After turning and sanding the two small balls, I stick the tenon into a block for support and saw the balls down the middle on the band saw. Then, saw the two halves free from the tenon.

Legs, Meet Carcase

The torpedo-shaped legs are attached to the case with sliding dovetails. This is a perfect way to set the cut-away surface tight to the sides of the cabinet and produce a strong joint. Another benefit of this method is that any error in placing the legs is easily corrected.

I begin by milling $\frac{3}{4}$ " wide, 8° dovetail slots in the carcase with my router,



Gently, now. A wooden handscrew provides sufficient pressure to push the knob tenons in place without damaging the faces.



Tiny turnings. The leg punctuation dots are held in a collet chuck and turned to shape using a file.



Safe cut. Use the tenon on the end of the ball to secure it in some sacrificial wood. Then cut each ball in half at the band saw.



Quick slots. A simple jig of $\frac{3}{4}$ " plywood guides the router's rub collar to make quick work of the leg dovetail slots.



Keys. Use mahogany scrap to make the keys at your table saw, then plane them for a precise fit before cutting them to length.

a $\frac{3}{4}$ " dovetail bit and a $\frac{3}{4}$ " outside-diameter rub collar. A template guides the rub collar and sets both the position and length of the dovetail slot (see photo above). With the template clamped to the case, I can cut the slots in a single pass.

Now mill some mahogany scrap to $\frac{13}{16}$ " thick, tilt your table saw blade, and cut both edges to 8° to match the slots. After testing the fit of the dovetail key into the slot, cut the keys free. With a few passes of a block plane, trim the keys to a precise fit, then cut them to length.

Drill a pair of countersink holes into each key, then screw the keys to the legs using $\frac{3}{4}$ "-long #6 wood screws. Check the fit and registration of each leg. Once you're satisfied with the fit and appearance, dismantle everything, apply glue, then reattach the legs.

With the legs glued to the carcase, glue the leg dots at the ends and tape them in place until the glue dries.

Then sand all surfaces to #220 grit (be careful not to cut through any veneer). If you have spray equipment, use it to apply at least two coats of satin lacquer. I've also experimented with General Finishes' High Performance Polyurethane Water Based Top Coat, which imparts a nice, protective sheen. (And of course, feel free to experiment with other finishes on scrap.)

Now all that's left to do is decide where in your home to display your elegant Ruhlmann-inspired work. **PWM**

Mario is a long-time furniture designer, maker and teacher; he now offers classes at the Philadelphia Furniture Workshop.



Applied keys. Screws hold the dovetail keys in place on the back of the legs.



Finishing touch. The dots atop each leg provide the final punctuation.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

WEB SITE: Visit the author's web site for information on upcoming classes.

VIDEO: See Mario Rodriguez's ingenious solution for scooping a chair seat.

TO BUY: "Building a Classic Drawer with Alan Turner" (who also teaches at Philadelphia Furniture Workshop).

Our products are available online at:

■ ShopWoodworking.com



Hand tools are the way to go for this traditional joint.

Tapered sliding dovetails are multipurpose joints traditionally used for drawer dividers, holding legs in place on a pedestal table and attaching tops to case pieces.

The primary reason for a tapered joint (instead of a straight joint) is the reduced friction over its length. The tapered sliding dovetail gets tight only during the final fit, when it is ready to seat home. This reduced friction makes fitting much easier.

Once the joint is seated, it is extremely tight and often requires no glue. Hand-cutting this joint is easier and quicker than the lengthy process of setting up a jig and machine.

After incorporating tapered joints into much of my furniture, I've found them strong and multifunctional; I believe you'll enjoy their benefits, as well as the challenge of cutting the joint, as much as I have.

Below, I'll show you how to create a small tapered sliding dovetail, such as would be used for a drawer divider.

Tail Layout

For this exercise, I use two $\frac{3}{4}$ "-thick x 4"-wide cherry boards (a typical size for a drawer divider).

The first step is to cut the tapered tail (after making sure that the end of your board is perfectly square).

Set a cutting gauge (not a pinned marking gauge, which would tear the fibers rather than cutting them) to $\frac{1}{4}$ " and scribe all around the end of the tail board to mark the baseline. On the board's edge, the sliding dovetail appears identical to a regular dovetail. However, from above, there will be a taper.

Place the tail board upright in your vise in preparation for marking tapered lines on the end grain. Starting with the

Tapered Sliding Dovetails

BY FRANK STRAZZA



Tail layout. After marking the baseline at $\frac{1}{4}$ ", mark the taper on the end grain.

end facing you, place a straightedge on the outside edge. Angle it toward the other end of the board, with a slope of about one-quarter the thickness of the board; in this case, that will be $\frac{3}{16}$ ". Draw a tapered line with a pencil along the straightedge. Repeat this process for the opposing side.

Using a dovetail marker or bevel gauge, draw the lines for the tail on the edge of the board. (I like a 1:7 angle.)

Cut the Tail

Cutting the angles on the top is a bit of a challenge, but no more than sawing a tenon cheek. Starting at the back, cut partway down your line, shift the saw to the front and make another partial cut, then join the two cuts. It is helpful to apply pressure between your thumb and the side of the saw to keep it aligned.

It's important that the two tapers on the end grain are straight and that the angles that make up the tail are cut accurately. Remember – you are only cutting down $\frac{1}{4}$ ".

Cut the Shoulder

With a knife, deepen the shoulder line that you marked with your cutting gauge.



Tail cuts. I use a dovetail saw to make the tapered cuts; notice how I use thumb pressure against the saw to keep it correctly aligned to the cut.



Now use a chisel to create a wall right against the knifed line. That creates a nice shoulder to set your saw against to use as a guide for accurate cutting. (This method is effective for extreme accuracy in cross-grain cuts.) But don't overcut! Inspect the tail to ensure that the shoulders are crisp and clean.

On occasion, I use a sliding dovetail plane to cut the tail, but I've found it not as effective for a narrow tail such as this one. (However, if you're creating a long

"Opportunity is missed by most because it is dressed in overalls and looks like work."

—Thomas Edison (1847-1931),
American inventor



Chiseled wall. Use a chisel to create a "wall" against which you can register your saw.




Narrow, then wide. First, mark the small end of the tail. (Note that your knife position is critical here, and be sure to mark both sides.) Then mark the wide end on the other edge of the pin board.

sliding dovetail, such as on a tabletop, the plane is essential.)

Mark & Cut the Pin

The next step is to transfer the tail to the pin. Mark two pencil lines square across the pin board to indicate the width ($\frac{3}{4}$ ") and placement of the tail board. Draw a face mark on the inside of your pin board on the right-hand side and another one on the right-hand side of the tail board. These marks should face each other; they will help you keep the alignment correct.

Lay your tail board on edge with the small dovetail end touching the pin board, with the end grain facing you. With your knife closest to the shoulder, mark the small end of the tail on both sides. Now flip the tail board end to end



Waste removal. Work in from both sides to remove the waste. On the wider side, a $\frac{3}{8}$ " chisel is the best choice; working from the narrower side, switch to a $\frac{1}{4}$ "-wide tool.



Cordless router. Level the floor of the socket using a small router plane.

so the end grain faces away from you. Mark the large end of the tail on the edge of the pin board closest to you, marking both sides right at the shoulder.

The key is transferring an image of the narrow section of the tail onto the pin board.

With a straightedge, join the marks for both tapers front to back. Then with a knife, lightly scribe along the straight-edge. Remove the straightedge and go

over the knife cuts several times to deepen the lines.

Transfer the 1:7 angles of the tail onto the edge of the pin board.

Using the same $\frac{1}{4}$ " setting on your cutting gauge, mark the depth of the pin recess.

As you did for the shoulder cuts, use a chisel in your layout lines to create a wall for your saw to follow, then saw down the length of the taper line, care-



Test. Now slide the tail into its socket; use a hammer to knock it home.



Truth. The finished sliding dovetail joint should seat firmly in place. If you've cut it perfectly, you don't even need glue.

fully following the angle of the tail. Be sure not to overcut.

Working from both sides, remove the waste using a $\frac{3}{8}$ " and a $\frac{1}{4}$ " chisel, with the bevels facing up.

With a small router plane, remove any excess material, bringing an even depth to the floor of the pin.

Now the moment of truth! Slide the tail into the socket and use a hammer to seat it tightly. If it's too tight and doesn't go all the way home, that's a good problem. Look at both ends, and you can usually tell where the problem lies. If it's too tight on one end, simply chisel away the material on the pin board. (If it's too loose, start over with a fresh pin board.)

And don't worry if your joint isn't perfect on the first try; it took me several practice sessions the first time, too. **PWM**

Frank is an award-winning furniture maker and a woodworking instructor at the Heritage School of Woodworking in Waco, Texas.



Great divide. The tapered sliding dovetail is my joint of choice to divide casework drawers.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

WEB SITE: Visit the Heritage School of Woodworking and the author's web sites.

VIDEO: Watch Frank Strazza demonstrate this technique in a free video.

WEB SEMINAR: "60 minutes to Better Furniture Design" seminar download, by Frank Strazza.

IN OUR STORE: "Made by Hand," by Tom Fidgen.

Our products are available online at:

■ ShopWoodworking.com

Kumiko Lamp

BY RANEY NELSON

The road to enlightenment is paved with lots of little strips of wood.

I am not by nature organized or detail-oriented. When I was young, I was the guy with the punk rock blaring and the messed-up clothes; the dog often ate my homework. Even as an adult, attention to detail is not my strong suit.

So it used to puzzle me why, as a craftsman, I'm attracted to detailed, obsessive and small-scale work. You'd think I'd have made a better chainsaw sculptor than infill planemaker.

I now realize my shortcomings are why I gravitate to things that seem out of character – because while I'm making tools and furniture I'm also working on myself. With each project, I improve my patience, my focus and my appreciation for details. And, in the end, making what's difficult is infinitely more satisfying than making what comes easily.

Though I'm still the unkempt guy with the music loud, work like this has made me a better craftsman.

Whether you're looking for spiritual attainment, are interested in taking your hand skills to the next level of precision or need an excuse to use a blowtorch, this Japanese-influenced



Andon-style lamp is worth the effort. It combines basic hand and power tools with a few purpose-made jigs – and a lot of attention to detail – to produce a beautiful reminder that patience is the key to wisdom.


Plus, you get to set it on fire. Sweet.

Materials

The lamp is basically a four-sided frame and panel, with an outer structure of flame-charred hardwood (see “Charred Finish,” page 40) and interior panels of softwood lattice.

For the outer structure (the legs), oak, ash and hickory look great with a heavy char, while mahogany and walnut look best with a lighter char to retain chatoyance and color.

For the lattice components, straight-grained softwoods work best. “Kumiko” is the general term for the strips of wood that go into the lattice, as well as for the work itself. Traditionally, Japanese hinoki cypress is the wood of choice for kumiko. In North America, both Alaskan yellow and Port Orford



Charred. Diffuse-porous mahogany (left) keeps some of its color and chatoyance, thanks to a film coat of shellac. Ring-porous woods such as oak (right) develop great texture as earlywood burns off.

cedars are similar to hinoki, and both finish beautifully. If you can't find these, white pine and basswood also work, though the results are not as crisp.

I made a pair of these lamps, one with oak and pine and the other with mahogany and Alaskan yellow cedar.

Kumiko Panels

I like to save the fun part (the fire charring) for later, so I start with the kumiko frames. All the kumiko are left

unfinished, so the surfaces should be planed clean with a sharp blade. The procedure I use to dimension the stock also leaves the pieces with a beautiful surface and an extremely consistent thickness.

Starting with boards milled and planed to $\frac{3}{4}$ " thick x 8" wide x 14" long, joint both edges square and flat. Then take one or two passes with a sharp plane over the jointed edges to finish this surface before sawing.


At the band saw, rip the panel-frame strips first, sawing $\frac{1}{16}$ " over the required $\frac{3}{8}$ " to leave enough material to thickness them later. Set the strips aside and take the board back to the jointer, and repeat the steps until you've got all your frame stock. Now rip the $\frac{3}{16}$ ", then the $\frac{1}{8}$ " kumiko stock using the same procedure.

Thicknessing Jig

For these short lengths of kumiko, a simple handplane fixture does a fine job getting consistent thickness. To make the fixture, rabbet three pairs of



Kumiko stock prep. Start with finish-planed $\frac{3}{4}$ "-thick boards. Joint both edges flat (left), then finish plane (center) before band-sawing strips a bit thick (right). This leaves just one surface to finish-plane after the pieces are cut.



Manual planer. The final side of the kumiko is finish-planed as it's thicknessed.



SUPPLIES

eShoji.com

eshoji.com or 262-644-7138

1 ■ Professional shoji paper
#B444, \$24.99



1 ■ Double-sided shoji tape
#Y1B, \$2.99

Westinghouse

westinghouselighting.com

1 ■ Make-A-Lamp Kit
#70269, \$10.56

Prices correct at time of publication.



MITER JIGS



Miter jigs. Nearly all the joinery and cutting of the kumiko happens in these two mitering jigs. Rip a groove about $\frac{3}{4}$ " wide x $\frac{1}{2}$ " deep in 8/4 stock. For this piece, 16" jigs will let you use both ends for different angles. You need, at minimum, one 90° end, one 45° end and one 22.5° end.



Adjustable stop. Take an offcut from a kumiko and cut a $\frac{5}{16}$ " slot in it for use as a stop in the jig. The stop needs to be about 4" long – you can drill several holes to mount it at different parts of the jig for different purposes. You can use pan-head wood screws, but I recommend drilling and tapping for $\frac{1}{4}$ "-20 machine screws instead.



Mitered cheeks. Rip cut at 45° for the tenon cheeks.



Trim the shoulders. A zero-set flush-cut saw rough-cuts the cheeks and removes the waste.



Pare to fit. Then pare the cheeks with a sharp paring chisel.

interchangeable tracks ($\frac{3}{8}$ ", $\frac{3}{16}$ " and $\frac{1}{8}$ "), then tune them with a shoulder plane for exact consistency.

The tracks are mounted to a dead flat, quartersawn board, plus a few #6 wood screws that serve as stops. Thickness all the $\frac{3}{8}$ " kumiko strips, then change tracks for the other thicknesses.

The inner frame of the panel, called a "tsukeko," is made from the $\frac{3}{8}$ " kumiko. I cut the mitered-tenon joinery by hand with my thinnest dozuki, but a good dovetail saw will suffice. (The tenons are $\frac{1}{4}$ " x $\frac{1}{8}$ " x $\frac{1}{8}$ ".)

For the mortised stiles, I follow the

same process shown above but rip cutting at 90°.

Most of the joinery for the inner frame is done using purpose-made mitering jigs (see "Miter Jigs" on the previous page). Set the length with the fence piece, and the jig ensures exact consistency on all the pieces.

Lattice

Now on to the $\frac{3}{16}$ " inner latticework. On each frame, there are three horizontal pieces and a single central vertical, all joined by half-lap joints. The two additional vertical dividers are not full-



Square cheeks. Rip at 90° for the mortised stile cheeks.

length, and they'll be added once the frames are assembled.

Cut the shoulders for the tenon centered on the end of all pieces. Pop the waste off with a chisel.

Lay out and cut the vertical piece by aligning the already-cut horizontal kumiko with its lower edge.

Next, use a pair of the middle pieces to mark the central half-lap on the remaining eight horizontals. Use the same middle pieces aligned with the bottom of the vertical lattices to mark them off; the spacing from the bottom is identical.

Finally, lay out the mortises in the outer frames using one of the vertical pieces and one of the outer horizontals. The mortises should be just more than

Kumiko Lamp

NO.	ITEM	DIMENSIONS (INCHES)			MATERIAL	COMMENTS
		T	W	L		
OUTER FRAME						
❑ 4	Legs	1½	1½	21½	Mahogany	
❑ 8	Rails	1¼	1¼	8 ⁵ / ₁₆	Mahogany	1" TBE*
❑ 1	Cross support	½	1½	7 ⁹ / ₁₆	Mahogany	½" TBE*
KUMIKO PANELS, OUTER FRAMES						
❑ 8	Rails	¾	¾	6 ⁹ / ₁₆	Yellow cedar	
❑ 8	Stiles	¾	¾	11¼	Yellow cedar	
KUMIKO PANELS, GRID						
❑ 4	Long verticals	¾	¾	10¾	Yellow cedar	⅛" TBE*
❑ 8	Short verticals	¾	¾	2 ¹³ / ₁₆	Yellow cedar	
❑ 12	Horizontals	¾	¾	6 ¹ / ₁₆	Yellow cedar	⅛" TBE*
KUMIKO PANELS, INSERTS						
❑ 32	Diagonals	⅛	¾	1 ⁷ / ₈	Yellow cedar	
❑ 64	Hinged pieces	⅛	¾	1 ¹³ / ₁₆	Yellow cedar	
❑ 64	Keys	⅛	¾	5/8	Yellow cedar	


*TBE = Tenon both ends

"Every man-made thing, be it a chair, a text, or a school, is thought made substance."

—Peter Korn (1951-),
from "Why We Make Things and
Why It Matters" (2013)



Gang-cut. Mark and cut the central horizontal kumiko carefully; they will be the template for all the other lap joints (as shown at right) as well as for the frame's mortises.



Half-lap lattice joints.

Start with the center horizontal pieces, which have three evenly spaced laps; you'll lay out the vertical laps from this piece to ensure consistency. Layout is simple if you've been precise – set a pair of dividers for 1½" and mark off three lengths from either side.



Ready for assembly. Here you can see the joinery on all the pieces that go together to form the inner structure.



Clamp both ways. While the glue cures, I work on the outer structure.

1/8" in depth – the wood in the mortise tends to compress significantly, so be sure to remove enough material that spring-back won't force the pieces out of their mortises.

I don't usually glue the half-lap joints, which are tightly press-fit. I use a dab of glue in each mortise, and I glue the four corners as well. Though the frames are tight fits, I leave them in clamps for several hours to ensure a good bond.

Support Group

The outer frame is straightforward. The four legs are mortised to receive 3/4"-square, 1"-long tenons, and both the legs and the rails are grooved to house the kumiko panels. The rail tenons are mitered to prevent meeting. That reduces the glue surface, so pay attention to the fit of the mortises, particularly at the small inner edge.

One pair of bottom stiles gets centered 1/4"-thick x 1"-wide x 1/2"-deep mortises for a cross support that will house the lamp cord and threaded pipe.

Cut the lamp support and fit its tenons, then drill dead center for the 3/8" threaded lamp pipe.

For the legs, mark the mortises and grooves for the kumiko frames, and cut the 3/16"-deep grooves with a router.

Then drill and chop the mortises, paying close attention to getting the long-grain faces square and smooth. Once done with the joinery, cut the large chamfered faces at the top and

bottom of each leg. Pay close attention to the orientation of the pieces – only the outer faces of the leg are chamfered – and leave about 1/2" of flat area at both top and bottom.

Light 'em Up

The charred finish on the lantern's outer skeleton is done with a propane or MAPP torch. It's a lot like airbrushing, but with much hotter (and cooler) pig-



Stopped grooves. I know of no good way to cut these grooves by hand, or I would. Routers were made for this.



Final shaping. Before lighting them on fire, finish-plane all the outer frame components and put a large chamfer on the long edges. I use a Japanese chamfering plane, which does a spectacular job of making consistent chamfers, but a block plane and some close attention does just as well.


ment. Once the pieces are cool enough to touch, buff the wax with a lint-free cloth or finish with a few coats of padded shellac to enhance the depth.

Fill in the Blanks

By now the inner frames should be ready for the insert work. First, cut and install the two remaining $\frac{3}{16}$ " vertical kumiko in each panel. These should be cut to a length of $2\frac{13}{16}$ ", with a single, centered half-lap joint in each. This can be marked off with dividers just as the lattices were.

Some words about fitting: Even if you've been painstaking, there will be small variations in length of the pieces, so the miter shooting jigs you made for the tsukeko will be in constant use.

The best approach when fitting a set of pieces is to fit to the largest gap first, then systematically shorten the setting of the jig's fence with hammer taps to fit each joint in order of size.



Burnt is the new black. I use a MAPP torch, held dead perpendicular to the surface, about 4"-5" away to char the wood. Once the color develops, while each piece is still warm, rub with burlap or a Scotch-Brite pad and paste wax to even out the color.

In this way, when you shoot a piece that is too large for any of the remaining openings, those few hammer taps will adjust the jig's fence length and allow you to re-shoot it for a perfect fit in the next-largest slot. Continue this process until you've finished all the installations.

Diagonal Fret Work

After installing the small vertical dividers, fit in the diagonals for each panel. Set the 45° jig fence to $1\frac{7}{8}$ " (just a bit larger than necessary). It's important to shoot both faces of one end before flipping the piece end for end, or the length will not work out correctly. Check the fit. Hopefully it's just a bit too large for all the openings, so tap the fence on the jig and re-shoot one end.


Continue until you have the piece fit to the largest opening, then shoot another piece to the same size and check its fit in all the remaining slots. If it fits any of them—great. Shoot another piece. Once a piece is too large for all the remaining openings, tap the fence closed a few thou and continue the process.

A Dash of Magic

While you might not realize it from looking at the opening photo, the outside-angled pieces of each quartered section are “hinged” — that is, the wood isn't cut all the way through where it bends.

Sizing the “hinged” pieces is trial and error, but the same length as the diagonal in the last step is a good place to start. Cut and shoot a $1\frac{7}{8}$ " kumiko strip as with the diagonals, but this time use the 22.5° shooting jig for an


CHOP MICRO-MORTISES



Tiny holes. Cutting such small mortises requires more finesse than most mortising. A single sharp blow with a $\frac{1}{4}$ " chisel defines the longer edges and severs the end-grain fibers.



Hide the evidence. Use a $\frac{1}{8}$ " chisel to pop waste from top and bottom, so that any compression marks will be hidden by the kumiko shoulders when installed.




The perfect pop. Waste should pop out like a little spiritual biscuit.



And insert. Check your fit and repeat the initial steps as necessary. With practice, I can get to sufficient depth with a single “pass” of my chisels.



Taking shape. First install the short vertical dividers.



Diagonals in place. Next, cut and install the diagonal inset pieces.



See & saw. A utility lamp, shining into the work at bench level, makes it possible to gauge by eye the depth at which to stop sawing.

included angle on each end of 45°. Use a marking gauge to mark a crosscut line at dead center for sawing.

You're going to saw this piece almost all the way through, but stop just a few thousandths of an inch short to leave a hinge that allows the piece to be folded for installation. This sounds impossible, but it's actually not hard if you work smart. The simplest and best solution is to use a sharp raking light that will let you see how close the saw teeth are to the bottom.

A dab of water on the bottom of the piece will help the hinge pop open cleanly; it should fold with nearly no force and remain intact. Install the piece in one of the panels and check its size. When pressed firmly into the corners, each leg of the hinge should just about bisect the corners. If it is too long, start over with a slightly shorter hinge piece. A bad fit will look sloppy, so try to get a good length worked out. Cut all the hinge pieces to the same length and install them in the panels.

The Keys

And now for the final pieces: the keys that lock the hinges and make the pattern complete. Each key is quite small, and you'll have to do the same sort of large-to-small sizing as you did for the diagonals.


Start by crosscutting all the keys from 1/8" stock at 5/8", which should be oversized. Shoot both faces of one end on the 22.5° jig. Then shoot the opposite end on the 45° jig and check the fit, resetting the fence and re-shooting as required. The piece should just slide in



Folded wood. The "magic" hinges are a result of careful and controlled sawing.



Keyed up. Lock everything in place with the keys and take a deep breath.



Stick 'em up. Double-sided tape beats traditional rice glue on all counts.

place with light force, locking the entire pattern solidly in place. If there is any wiggle, the key is too small. Don't force a piece, though, because this will distort (or break) the lattice. Again, work from largest opening to the smallest.

Shoji Paper

The last step before assembly is to install paper on the inside of each panel. Traditionally, this was done with rice glue, but I find modern shoji tape simpler to install and repair. Put the tape around the perimeter of the tsukeko frame and remove the backing. With your shoji paper flat and face up on the bench, put the frame on the paper and press gently to adhere the paper. Trim the edges to the frame with an X-Acto blade.

To get the paper drum-taut, spritz it lightly from the rear with water. This will make the paper sag slightly, but once it dries (20 minutes) it will be tight and seamless.

Wrap it Up & Turn it On

The glue-up is best done in two stages. Glue the front and rear sections first, then install the lighting hardware in the cross support. I used a lamp kit from

my local big box store. I recommend an inline cord switch over a socket-mounted one to keep from having to reach in to turn the switch.

Once the front and rear panels are dry, install the remaining panels and stiles, and do the final glue-up. After the glue dries, power up your new lamp and enjoy some good punk rock (loud, of course) and a beverage while you bask in the glow. **PWM**

Raney is an infill planemaker and woodworker at Daed Toolworks (daedtoolworks.com); his shop is located near Indianapolis, Ind.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

WEB SITE: Visit the the Daed Toolworks web site to see Raney Nelson's infill planes and read his blog.

TO BUY: For more on Japanese latticework, the author recommends Desmond King's "Shoji and Kumiko Design: Book 1" and Toshio Odate's "Making Shoji."

IN OUR STORE: Make a simple "Shoji-Paper Lamp," an article by Christopher Schwarz.

Our products are available online at:

■ ShopWoodworking.com

Charred Finish

BY SETH GOULD

Fire and wax together produce a rich black surface.

Fire might not be the first finishing technique that most woodworkers gravitate toward; then again, I am not most woodworkers.

As a blacksmith and toolmaker, I am around fire every day, and when I began burning my hammer handles, I found it to be a simple way to obtain an alluring surface that set my work apart. It is unlike any other finish I have seen,

and it really stands out on its own.

I don't claim any ownership over this application, because I am sure at some point I saw another blacksmith's handle done this way. But by now I have done it enough to feel comfortable sharing this technique.

Beyond the charred oak barrels used in distilling spirits and some use of fire finishing in Japanese architecture, I

have been hard-pressed to find mainstream examples of burnt wood used as a finishing technique.

Material Options

In my experience, open-grained hardwoods such as hickory, oak, walnut and mahogany produce the best results for this technique. With these, the softer earlywood tends to burn away faster, leaving a varied surface texture that looks and feels great after charring.

Woods with a more closed grain, such as maple and cherry, keep their smoother surface and don't turn out nearly as compelling. Softer woods such as pine and cypress tend to burn too quickly and have a ragged appearance.

Beyond the species, two factors to keep in mind are moisture content and thickness. If the wood is too wet or too thin, it is prone to warping or cracking. Any well-dried wood should be fine, but stay away from anything green.

I tend not to burn wood that is less than $\frac{5}{8}$ " thick. The smaller dimensions are unpredictable and especially prone to bending.

One way to combat this is to use straight-grained wood to help prevent unwanted movement.

The Process

For a charred finish, you will need a piece of abrasive cleaning pad (such as Scotch-Brite), paste wax, a rag and some sort of flame. I use my acetylene soldering torch, but an inexpensive propane torch or MAAP torch will work just fine.

The beauty of the technique is that the wood can be surfaced to a rather rough state, and, through the process of burning, the end result is a refined surface. I usually don't go beyond a fine



Tools. A torch, some wax and an abrasive pad are all you need to produce a rich black finish.

Results. This hammer handle with a charred finish has one coat of wax that was added while the wood was warm and buffed with a rag once it cooled.



Hot surfaces. This side-by-side comparison shows how much the charring technique refines the surface of the wood; there's no need to sand before burning.



In motion. Use the torch to char the wood evenly, constantly moving so you don't burn away too much material in one spot.

"Keep a little fire burning; however small, however hidden."

—Cormac McCarthy (1933-),
American author



Wax on. Use a liberal amount of wax; the wood really soaks it up once it liquefies.



Fast finish. With about 30 seconds of scouring, you can skip an hour of sanding.

rasp for my shaping and finishing; the torch takes care of the rest.

When putting the flame to the wood, don't be too aggressive at first. I approach the wood with the torch and move up and down the material so I am not lingering on any one place with the heat. By constantly moving the flame, the wood will burn evenly and be less prone to bending, warping or cracking. Also, if you stay in one spot, you run the risk of burning away too much material and creating a depression.

If the wood flares up, I simply blow it out and continue burning. I keep going over the piece until I can no longer see the color of the wood and there is an even black char on all the surfaces.

For some applications, however,

partial burning can be an attractive alternative as well. Experiment!

Next, use your Scotch-Brite pad to scoop up some paste wax and aggressively rub it into the wood. This works best while the wood is still warm so the wax melts and spreads around.

As you scrub, the charred particles will be picked up by the liquid wax and help to blend any unevenness. Once you have given the piece a good scouring, wipe off the excess wax and let it cool.

At this point, if you see any spots that seem light or uneven, you can go back and burn a little more. This will burn off any wax you have already applied, so you will have to reapply where necessary.

When the piece cools, you can add

more wax to build up the finish, but I usually just buff with a rag and call it a day.

For me, this technique is purely aesthetic, so my experimentation has been rather limited. There are many places this finish could be used, though—such as woodworker Tom Shields does on his contemporary work.

For another charred finish example, see "Kumiko Lamp" on page 33 in this issue. **PWM**

In furniture. Tom Shields, who has work in many museum collections, is a fine example of a contemporary furniture maker who uses the charred finish technique in his work.



Seth is a metalsmith who lives in Cleveland, Ohio. His work has appeared in numerous exhibitions and publications, and he regularly lectures on his craft.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

WEB SITE: Visit the author's web site at sethgoold.com for a look at his metalsmithing.

WEB SITE: See more of Tom Shields' work at tomshieldsart.com.

TO BUY: If you like playing with fire, check out Peter Ross' blacksmithing videos.

Our products are available online at:

■ ShopWoodworking.com

Curve Appeal

BY NEIL CRONK

This stool builds your skills with eight different joints and bent laminations.

Competition is the whetstone of talent; this was in full effect when I built this Wharton Esherick-inspired stool for an online shop stool build-off hosted by Flair Woodworks. It was the perfect opportunity to try out a design that had been floating around in my head for a few months – and I won, so I count it as a success.

The stool provides an exercise in bent laminations and eight different joints: angled mortise-and tenons, both straight and angled drawbored mortise-and-tenons, a pegged slip joint, several different types of lap joints, dovetails and wedged through-tenons. Broken down step-by-step, this project is remarkably simple to build – even if you're new to the techniques.



Drawing. A full-scale drawing helped me work out the joinery, but it also serves as a template for the final design.



I fiddled with the design by drawing the stool's profile full-scale on some scrap plywood, playing with the proportions of components and joinery for each connection until I was satisfied. Then, I used the full-scale drawing as a template for the parts, and as I laid out some of the joinery.

I also made a plywood full-scale drawing of the bottom to use as a layout template, and a router jig to locate the handhold on the underside of the seat.

White oak was my choice for this project because it bends easily, so I knew it would work for the bent laminations on the legs. Also, I just like working with white oak.

Start at the Top

Start by laying out the parts on an 8"-wide x 8' long 8/4 chunk of white oak and rough-cut all but the leg stock. For the legs, select one full-width piece of stock that's at least $28\frac{3}{16}$ " long (try to find a piece with a rift-sawn edge for the curved laminations). Working with an uncut piece makes it easier and safer to joint then cut the bent-lamination plies on the band saw.

The seat is 11" wide, so if you don't have a board wide enough you'll have to glue up two pieces; try to slip-match them to provide the illusion of a single piece. Clamp and set that glue-up aside to dry while you work on the curved portion of the legs.

With the leg material planed to $1\frac{1}{2}$ " thick, draw carpenters' triangles on the face so you can get the plies back in the same order after milling them.

Rip $\frac{1}{8}$ "-thick strips off the edge, jointing between each cut.

Cut 13 strips for each leg, then plane them to $\frac{3}{32}$ " to make up the $1\frac{1}{4}$ "-thick bent laminations. The remaining wood is the stock for both of the straight legs.

For lamination glue-ups, I've used both Old Brown Glue (liquid hide glue) and polyurethane Gorilla Glue. Both work well and have rigid glue lines, though I had a bit more squeeze-out to clean up with the Gorilla. I know many woodworkers prefer plastic resin glue for laminations because there's no creep, but I didn't have any on hand. (See "Bent Lamination Form" for how

BENT LAMINATION FORM

For my bent lamination work, I build a form with the required radius (in this case, $8\frac{7}{16}$ ") out of three layers of $\frac{3}{4}$ " plywood. For this form, the final length and width is approximately $15 \times 11\frac{1}{2}$ " – those dimensions needn't be exact; you simply need to be able to fit the clamps.

First, lay out the radius on the corner of a squared-up piece of plywood then "Price is Right" the line by cutting as close to it as you can without going over (I use a band saw, but a jig-saw works, too). Clamp the plywood into a vise and use a spokeshave to fair the curve to your layout line.


Trace the curve onto another piece of plywood, then cut close to that line and glue and screw it to the first piece, leaving a small amount overhanging the edges.

Use a pattern bit in a handheld router to match it to the first piece, then repeat this step once more to get to three layers in total.

Set a combination square to 3" and draw a line in from the edge, then drill $1\frac{1}{4}$ " holes centered on that line for the clamp heads.

Cut six $2\frac{1}{4}$ "-wide strips of $\frac{1}{8}$ "-thick Baltic birch plywood to act as clamping cauls.

— NC




Clamp holes. After gluing up the bending form, use a Forstner bit to drill $1\frac{1}{4}$ " holes for the clamp heads.




Lamination plys. I use the band saw to rip $26\frac{1}{8}$ "-thick strips for the bent lams. The remaining wood is the stock for the straight legs.



Now plane. If, like mine, your planer has a minimum depth of $\frac{1}{8}$ ", add a melamine or smooth plywood sub-base to get to the required $\frac{3}{32}$ " thickness.



PROFILE



3D VIEW

I construct a jig for this process – and you'll need two forms, or time for two sessions of lamination bending.)

If you're using polyurethane glue, spritz water onto both sides of the plies (not necessary with hide glue or plastic resin) then spread the glue on, stacking the plies together one at a time. With the triangles lined up, wrap masking tape around one end to make it easier to align the plies as you start adding

the clamps.

Start with a big bar clamp at the end that will have the bridle joint, then work your way out from there with F-style clamps. Use your hip to push the plies toward the form as you add and tighten each clamp.

Seat Mortises & Tenons

With the seat milled to final size, lay out the four mortises on the underside.

The two at the back are 1/2" thick x 1" wide, located 1/2" from the back edge and 1 1/8" from the sides; they get cut to a 1" depth. The two at the front are 7/8" thick x 1" wide, located 7/8" in from the front and 1 5/8" in from the sides; they get cut to a depth of 5/8".




Remove most of the mortise waste with a Forstner bit at the drill press.

With the same setup, cut through-mortises on one edge of the plywood

Work around. The first clamp to apply is the bar clamp across the end; then work around the form using F-style clamps to pull everything tight.



Waste away. A Forstner bit makes quick work of removing the bulk of the mortise waste on the underside of the top.



Reference mark. Before you take off the clamps, make a pencil mark where the flat starts.



Cleanup. A small block plane makes quick work of cleaning off glue squeeze-out.

seat template, widening the one for the straight legs (at the front) to $3\frac{1}{2}$ ". That way, you can use the same holes to lay out the half-lap locations for both the right and left leg intersections. (See the jig in use on page 48.)

Use a bench chisel to clean up the corners for the four mortises in the seat bottom and double-check to make sure they're the correct depth.

Clean up the drilled mortise corners on your seat template, too.

Now mill the pair of straight legs

to $1\frac{1}{4}$ " square. Cut both ends to 25° , leaving an extra 1" at the bottom to allow for leveling the stool after glue-up.

Before fully removing the clamps from the laminations (wait at least 24 hours), mark the edge where the flats start so you can easily match up the pair.

Now transfer the marks from the edge to the inside faces so you don't lose them when the edges are jointed.

I use a block plane to clean up the foamy squeeze-out from the Gorilla Glue before jointing the edge with my

power jointer.

Now edge-joint the bent laminations. Make sure the convex side is riding flat against the fence and confirm that the edges are square before planing them to a final thickness of $1\frac{1}{4}$ ".

Line up the marks indicating the starts of the flats on the bent laminations, then clamp and screw the ends together in the offcut area.

As is to be expected, I had a small amount of spring-back when I pulled the bent legs out of the clamps. To fix

"It is far better to work with one plane, one saw, one chisel and a few accessories, all of them good, honest steel, properly sharpened, than it is to have a cellar full of inadequate devices."

— "How to Work With Tools and Wood,"
Stanley Tools (1942)



Joint. With the outside edge riding on the fence, joint the laminated glue-ups to $1\frac{1}{4}$ " thick. Make sure the pieces are square.

this, I simply used a block plane and spokeshave to remove a small amount of material where the front stub leg attaches, bringing the piece back into line with my template.

With everything squared up, place the curved bits on the full-scale drawing and, with a marking knife, mark the locations of the $\frac{1}{2}$ "-thick x 1"-wide seat-tenon shoulders. Use a square to help carry the marks around both parts.

For the female part of the bridge joint, knife in the shoulder of the joint on the bottom outside joinery surface, then use




Small adjustments. With only minor spring-back at the joinery surface, it was an easy call to remove a small amount of material to flatten the joinery surface. Such minor adjustments are invisible in the finished piece.


a bevel gauge set to 2° to lightly transfer that up the sides; use a square to mark the shoulder on the inside face of the curve. I use a pencil to mark the ends of the part, again wrapping around the pair.

I cut the bent laminations to length using a handsaw with the help of a bench hook, holdfast and clamp. Before cutting, wrap some tape around them to hold the pair together after the screwed ends are cut free.

With the bent laminations and straight legs cut to size, and the tenon shoulders laid out, lay out the tenon cheeks on the top of the bent lamination. I find it hard to see gauge lines on white oak, so sometimes I put some green tape on the end grain before layout. When I gauge the lines, it cuts the tape; that makes the cutline easy to see.



Taped up. Tape helps to hold the bent laminations together as you cut them to length.



Cheeky. Colored tape helps me see and cut to my knife lines.

For the straight-leg layout, use the full-scale drawing to locate and mark the tenon shoulders using a square and a bevel gauge set to 25° to wrap the line around. Show the legs to their seat mortises to mark out the cheeks. I use a square and marking knife to mark those lines from the end to the shoulder line.

I cut these with a handsaw then fit them to their mortises.


Join Stub Legs to Curved Legs

With the stub legs milled to $1\frac{1}{4}$ " square x $14\frac{5}{8}$ " long (that includes an extra 1" for leveling), use a marking gauge set to the thickness of the curved legs ($1\frac{1}{4}$ ") to mark the square shoulder for the bridge joint on the backside of the stub legs.

Set your bevel gauge to knife in the angled shoulders of the male portion of the bridge joint, then square across the front.

To lay out a bridge joint, I like to use a dual-wheel marking gauge with both cutters set to the same measurement. With one bevel facing in and one bevel facing out, I can use it to lay out both the male and female parts of the joint with the same gauge. Use the stem with the cutter's bevel facing the gauge's head to lay out the male portion of the joint. Use the other stem to lay out the female portion of the joint. This gauge set-up will ensure accurate knife lines.

Lay out the cheeks using the gauge set to $\frac{3}{8}$ " – leaving $\frac{1}{2}$ " in the middle – then cut to those lines on the band saw or with a rip saw, depending on your preference. I cut the shoulders with a crosscut saw and used a coping saw to



Straight-leg tenon. Use the full-scale drawing to locate the layout for the tenons atop the straight legs.

'Curve Appeal' Stool

NO.	ITEM	DIMENSIONS (INCHES)			MATERIAL	COMMENTS
		T	W	L		
❑ 1	Seat	1 ⁵ / ₁₆	11	14 ¹ / ₂	White oak	Bevel sides and front
❑ 2	Long legs	1 ¹ / ₄	1 ¹ / ₄	28 ³ / ₁₆ *	White oak	Tenon one end
❑ 2	Curved legs	1 ¹ / ₄ **	1 ¹ / ₄	21 ⁵ / ₁₆	White oak	Tenon one end
❑ 2	Stub legs	1 ¹ / ₄	1 ¹ / ₄	14 ⁵ / ₈ *	White oak	
❑ 2	Side stretchers	³ / ₄	1	12 ⁷ / ₁₆	White oak	
❑ 1	Rear stretcher	³ / ₄	1 ³ / ₈	11 ¹¹ / ₁₆	White oak	Dovetail both ends
❑ 1	Foot rest	1	1 ³ / ₄	12 ⁵ / ₈	White oak	Tenon both ends

*Includes extra for leveling **Final size; start with 2¹/₂" or thicker stock to account for lamination saw kerfs



Dual cutters. Set both blades to the same measurement and use one gauge for the mating parts to ensure accurate lines.

remove the middle waste. Clean up to the lines with a chisel.

To glue up this joint, make a curved block screwed and glued to a ¹/₈" plywood caul with the end cut square and in line with the joint. With a couple of notched cauls, glue up the joints with liquid hide glue. When the glue is dry, drill a ¹/₄" hole in the center of the joints, then pin them with a riven oak dowel.

Dovetailed Stretcher

For the dovetailed rear stretcher, cut a ¹/₄" deep rabbet, 1⁵/₁₆" from the end of the stretcher. This makes it easy to register the stretcher to the leg as you mark the baseline for the second tail. Plus, it reduces the thickness of the tail, so its socket is ¹/₂" deep to maintain the legs' structural integrity.


Then, with the straight legs in their seat mortises, butt the rabbeted shoulder of the stretcher against its leg and mark the other shoulder with a knife.

Mark that shoulder and again cut a rabbet. Now lay out and cut the dovetail pins (I like a 10° slope). Locate the stretcher at its final location across the straight legs, then scribe the sockets and mark the baselines on the legs.

Remove the stretcher, cut the edges of the socket and add a few more kerfs in the waste to make it easier to chisel the waste out. After removing the bulk of the waste with a chisel, clean up to the baseline with a router plane. Fit the joint, but don't glue it up just yet.

Leg Half-lap Joints

Using the plywood seat template, place the bent-lamination tenon into



Bridle joint glueup. A curved caul with a "tail" that registers along the length of the curve will help you clamp this joint together as the glue sets.

the tight-fitting mortise and place the straight leg into the slotted mortise, making sure the shoulders are tight.

Place a clamp across where they meet. Lightly mark out the shoulders of the half-laps, then extend the lines down the edges and use a marking

gauge set to ³/₈" to mark the baselines.

I use a wide chisel to deepen and notch the straight shoulders on the curved legs; that creates a shoulder that serves as a guide for a perfect saw cut. On the straight legs, remove the bulk of the waste and pare with a small



Mark the stretcher. A rabbeted shoulder on one end makes it easy to register the stretcher against the leg as you mark the shoulder location at the other end.



Sockets. Place the stretcher in its final location, then use a clamp across the legs to pull them tight to the rabbeted shoulders. Mark the dovetail sockets on the legs.



Lap layout. With the legs registered in the seat layout jig, clamp across where they meet, then mark the shoulder locations on each piece for the half-lap joint.

chisel to establish the curved shoulder. Use a router plane to clean up the floor on both halves.

Footrest: Wedged Tenons

To lay out the through-mortises for the footrest's wedged tenons, align the stub-leg tops and clamp them together.

Now mark $\frac{3}{4}$ "-long x $\frac{1}{2}$ "-wide through-mortises, $2\frac{7}{8}$ " down from



Half-lap waste. After cutting a series of kerfs with a handsaw, I use a chisel to remove the bulk of the half-lap waste. A router plane cleans things up for final fitting.

the top of the stub legs. I mark them on one face, then lightly wrap the lines around to the opposite face to ensure they align.

Using a drill press and Forstner bit, remove the bulk of the waste coming from both sides, then clean up the corners with a chisel. Though this is a wedged mortise, I cut and fit everything straight, then flare the mortise.

The footrest has one through-tenon that will be wedged and two ears that wrap around the front and back of the

leg; I call it a "triple tenon" (only the center portion is integral to the joint).

To make it, cut the center tenon $\frac{1}{2}$ " wide, then cut the shoulders of the short ears. Cut the center tenon to final thickness with a handsaw, then fit it with a router plane as necessary. Slide the tenon into the mortise and mark the outside cheeks, then cut them with a handsaw. Remove the middle waste with a coping saw and chisel.

When wedging a tenon, I saw the tenon kerfs, insert the wedges, then measure the tenon width so I know how much to flare its mortise (in this case, $\frac{1}{8}$ "). Lay out the extents of the flare, then cut the slopes with a chisel.

Drawbored Side Stretchers

The side stretchers are installed with angled mortise-and-tenon joints that



Through-mortise layout. Here's the marked layout for the footrest's mortises.



Measured flare. Insert the wedges into the unseated mortise, then measure the flare. Use a chisel to pare the mortise

Guided paring. A block cut to the desired angle (in this case, 25°) helps guide your chisel for perfect paring.



Eased corners. The "ears" of the footrest's front get rounded with a rasp and files.

are drawbored into the straight legs and attached with a drawbored lap joint to the front stub legs.

Lay out the $\frac{3}{8}$ "-thick x $\frac{3}{4}$ "-wide x 1"-deep mortise, $\frac{1}{4}$ " in from the outside edge of the long straight legs. Hog out the angled mortises at the drill press, then use a purpose-made ramp to guide your chisel as you pare the 25° slopes.

Lay out the tenons to match and cut them. I cut the shoulders and cheeks with handsaws and tweak them as needed with a router plane.

This joint gets drawbored, so with a piece of scrap in the mortise (to help limit the depth), drill a centered $\frac{1}{4}$ " hole, $\frac{3}{8}$ " in from the edge.

To mark the drawbore, insert the matching tenon and, with the shoulders tight, use a $\frac{1}{4}$ " drill bit to mark the center of the hole.

Remove the tenon and offset the hole center $\frac{1}{16}$ " toward the shoulder, then drill.

Re-insert the rear tenon and pull it in place with a drawbore pin, then mark and cut the lap-joint layout on the front leg and stretcher. Drill $\frac{1}{4}$ " drawbore holes for the half-lap, too.

Shapely Seat & Footrest

Now you're ready to excavate the handle on the bottom of the seat, bevel its underside edges and shape the footrest.

Make a handle template out of $\frac{3}{4}$ " plywood by drilling two $1\frac{3}{8}$ " holes 3" apart, $2\frac{3}{4}$ " in from the edge. Cut the



Get a handle on it. A router template makes it quick and easy to cut a handle on the underside of the seat.



Take it in stages. Glue up is best done in a well thought-out order, and in stages.

flats between them with a jigsaw and clean them up with a rasp. Attach a piece of $\frac{3}{4}$ " plywood to serve as a fence, then center the template on the seat and clamp it in place. Rout the waste with a template bit to a depth of $\frac{5}{8}$ ". I used a $\frac{1}{4}$ " radius bit to round over the edges.

To lighten the seat, cut a bevel on the bottom of the front and both sides. I set my table saw to $37\frac{1}{2}^\circ$, and, starting with the end grain sides, made the cuts. Clean up the tool marks with a block plane.

With a block plane, rasp and file, round over the front edges of the footrest and chamfer the back edges.

All Together Now

Before gluing up, make sure all surfaces have been smoothed with a handplane, spokeshave or card scraper (or sandpaper, if that's your preference).

As with most projects, this one is glued up in stages, with ample drying time between each.

With the legs in position on the seat to keep things properly aligned, glue up the wedged through-mortise footrest on the front legs, and the rear drawbored mortise-and-tenon joint of the side stretchers to the back legs. After the glue is dry, flush and clean up the joints as needed.

Next, glue up the leg half-lap joints, the front drawbored lap joint on the

side stretchers and the dovetailed rear stretcher. (Again, after the glue dries flush and clean up the joints as needed.)

Finally, glue the legs into the seat bottom, using angled cauls to seat the clamps at the front and pull that joint tight (see photo at left). Drawbore the tenon atop the curved leg through the back edge of the seat; no clamps are needed there.

Before finishing, the stool needs to be leveled. To do this, I place it on my bench (a known level surface) and insert wedges under the legs as necessary until the stool is level to the bench.

Then, using a block of wood that's just thicker than the wedges, set a pencil on that block, and mark around the bottom of each. Cut to the lines with a crosscut saw. (You might also wish to lightly chamfer the edges of the legs to keep them from splintering at the bottom corners as the stool gets dragged across a floor.)

Before applying a finish, break all the edges with #220-grit sandpaper and clean up any remaining tool marks or marks from the clamps. Also cast a close eye over the piece to look for any glue squeeze-out; clean up with sandpaper or scrapers as necessary.

To finish the piece, I applied a wash-coat of one-pound-cut shellac, followed by two coats of polymerized tung oil (with ample drying time between coats) that I applied by wet-sanding with #600-grit wet/dry sandpaper for a smooth finish. **PWM**

Neil is a woodworker, toolmaker and furniture designer in Dartmouth, Nova Scotia. You can see more of his work at cronkwrightwoodshop.com.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

WEB SITE: Visit the author's web site for a look at his other furniture pieces and tools.

PLAN: Download the SketchUp model for this project.

TO BUY: "Chairs & Benches," a collection of 17 seating projects from Popular Woodworking Magazine.

Our products are available online at:

■ ShopWoodworking.com



***Built in Baltimore.** While many people associate Jennie Alexander's chairs with country woodcraft, she lives in urban Baltimore, where she developed the design for her chair.*

Make a *Revolution* from a *Tree*

BY CHRISTOPHER SCHWARZ

A curious attorney helped
kick-start 'green woodworking'
with a single chair and a book.

Of all the unusual twists and turns in the life of Jennie (formerly John) Alexander, surely the most incredible has been to be pronounced dead in the media while being very much alive.

When her second woodworking book was released, "Make a Joint Stool from a Tree" (Lost Art Press), some reviewers said she was deceased; others assumed "Jennie" was John's widow.

So let's set that fact aside – John is now Jennie – because it has nothing to do with Alexander's incredible woodworking career, the iconic chair she designed or her profound influence on woodworking during the last 37 years.

Alexander's first book, "Make a Chair from a Tree" (Taunton Press and later Astragal Press), was the 1978 lightning bolt that ignited the woodworking passions of thousands of woodworkers and brought "green woodworking"

out of the forest and into the modern workshop. Even after the book went out of print, the chair continued to inspire through a DVD of the same name published by ALP Productions.

The chair that is featured in the book and DVD is both old and new. While it is based on traditional ladderbacks and deep-lignin science, Alexander's chair is not tied to a particular period or style. Its parts are shaved instead of turned. It looks at home in a log cabin or an urban loft. It weighs almost nothing but is as strong as a suspension bridge. And it is definitely the most comfortable all-wood chair I have ever sat in.

There is something about the back that is simply incredible. The two slats hit you in the right place, and the back legs are curved in a way that pleases your eye and your muscular system.

As soon as I sat in one of her chairs, I knew I had to make one.

I'm not alone. Thousands of chair-makers have been smitten with the design. And many of them, such as chairmaker Brian Boggs, went on to become professionals. So if you are one of the tens of thousands of people who now build chairs from green wood or carve spoons or bowls, you are almost certainly part of the lineage that began – in part – with a Baltimore boy who was handy around the house.

Obey Snowball

Born in December 1930, Alexander was the son of a mother who was a secretary to the president of an insurance company. She would leave a to-do list for Alexander to tackle after coming home at night. She arranged for Boulevard Hardware to provide tools from the store's extensive stock of Stanley tools. Jerry and Miss Irma at Boulevard filled the bill.

The owner also gave Alexander handouts on tool use that were printed by Stanley Tools, which Alexander kept in a three-ring binder, including a guide to sharpening and using hand tools.

"That," she says, "was my bible."

Another important part of the home picture was that Alexander's mother, a former Sloyd student in Massachusetts, had collected some old furniture, in-



Broken chairs. Alexander's research has been informed by many bits of research, including looking at bits of chairs that have broken to learn why they failed.

cluding a post-and-rung chair with a fiber seat. "It had always been there," Alexander says about the chair. "I liked that chair. It was comfortable, low and stocky but had an elevated air to it."

Alexander attended Baltimore City Polytechnic Institute, a four-year high school that specialized in engineering—graduating there would give her a year's head start at university. In high school she studied engineering with extensive shop work, from combustion to electricity to woodworking – things that stuck in her scientific mind and would come in handy later on when bending chair parts with heat and moisture.

After graduating, Alexander enrolled at Johns Hopkins University as a sophomore to study engineering. But she was shocked to learn the school was teaching the same material from high school, but to four decimal points of precision instead of two.



Almost homemade. Alexander enjoys making effective tools from inexpensive raw materials. Here, she made a useful side hatchet from a standard double-bevel hatchet.

"I was bored," she says. "I was interested in music."

She founded a repertory jazz trio and played around Baltimore, playing piano in bars instead of studying. She left Johns Hopkins and went to night school to study mathematics. Then she quit that, got a job as a draughtsman and then at a war plant – all while singing and playing jazz piano with the Southland Trio.

But one morning, Alexander was lying in bed unable to sleep and heard a voice from her childhood speaking to her. It was the voice of Snowball, a voice on the radio show "Uncle Bill and Snowball," which featured a blind banjo player who would sing in the high falsetto voice of Snowball.

"Go to law school," Snowball said. Alexander took the disembodied advice and by 3:15 that afternoon had enrolled in law school at the University of Maryland at Baltimore.

Alexander graduated law school in four years instead of three because she decided to attend night classes to prevent her from playing jazz on weeknights. After coming in first on the bar exam, Alexander married "a wonderful girl" named Joyce, now deceased, and started a traditional law career. Which might have been the end of the story if it weren't for meeting Charles Hummel at Delaware's Winterthur Museum.

Shaker Chairs

Like many young people, Alexander and Joyce fixed up an old house; Alexander started reading English books on traditional trade, including chairmak-



Boring the joints. Alexander demonstrates boring the mortises in a leg using a benchtop fixture that simplifies the process.

ing. She fixed up a fishing boat (which later became a pond for storing wet wood for chairmaking), started making stools and decided to make some chairs.

"I called a firewood man and said I want a hickory log so long and so straight," Alexander says. Later on, "I hear a great sound at the back. He's dropping off hickory logs. Don't ask me how I broke those down to get them on the lathe. But it's time to make a chair. I got those legs up on the lathe, and the lathe was jumping across the room.

"When the rough, split spindle finally turned round, 6'-long sopping-wet strands of hickory traveled up the gouge and hung themselves up on my right ear. I said, 'I will never go to the lumberyard again.'"

And she never has.

Alexander and Joyce were fascinated by the Shakers. They made several trips to the Sabbathday Lake Shaker community in New Gloucester, Maine, where Sister Mildred there became Joyce's "spiritual guide." Alexander decided to make a Shaker chair with a one-slat back.

"So I made some very clunky Shaker chairs with one slat and we used fake twisted paper (instead of rush or tape for the woven seat)," she says.

In the meantime, Alexander joined the Early American Industries Association (EAIA) and met Charles Hummel, author of the book "With Hammer in Hand" (University Press of Virginia) and a curator at Winterthur.

With Hummel's guidance, Alexander became an expert on antique chairs made by the Dominy family on Long Island, including one interesting chair in the study collection that could be disassembled when the humidity is low (she was permitted by the museum to disassemble the chair, by the way).

All of this led Alexander to experiment with wet wood. To test theory after theory on joinery, moisture content and how wood behaves. Some of the chairs work fine. Some do not.

At some point she decided to write a book about her chairs and traveled to New England in 1977 at the suggestion of fellow craftsman Richard Starr. Alexander says she and Starr visited John Kelsey, the editor of *Fine Woodworking* magazine, at his home with a draft of the manuscript for "Make a Chair from a Tree" (Alexander says she "just happened to have the draft in hand").

"Kelsey read the draft overnight and hired me in the morning," Alexander



'Make a Chair' on a chair. Alexander's first book – "Make a Chair from a Tree" – sitting on a chair made by Larry Barrett, one of Alexander's many students.

says. "Kelsey also hired Bruce Hoadley to read the text. Hoadley advised Kelsey, and I listened to every word."

'Make a Chair From a Tree'

"Make a Chair from a Tree" was the first woodworking book published by Taunton Press, Alexander says. At the time, the new magazine was just getting started working on books with Tage Frid and Bruce Hoadley, but Alexander was ready to go, says Kelsey, the then-editor.

"I remember thinking it was a perfect topic for the then-new *Fine Woodworking* audience, the concept was so elemental and fundamental, and so unlike anything then in print; it cut to the very core of what we were trying to do," Kelsey says. "At the same time, the publisher, Paul Roman, had a more conventional view of our woody audience and judged it a risky proposition, perhaps a very hard sell. But we didn't

"The faster a thing is created, the more fleeting its permanence."

—Friedensreich Hundertwasser
(1928-2000),
Austrian artist & architect

WHAT MAKES A 'JENNIE' CHAIR?

During a 2014 interview with Jennie Alexander, she explained some of the features of her chair that she thought were critical to its strength, comfort and beauty. Here are a few of her comments.

On support:

"What is the lumbar spine about? Slat-chair people want to use seven slats – some slats are above your head. Is the chair beautiful? Oh yes, it's a wooden octopus. But is it comfortable? Some day you are going to find the lumbar spine."

On her chair design in comparison to a ladderback kitchen chair:

"My first one-slat chairs were too heavy with hickory and big parts. I asked: Can we lighten it up? I always thought of the kitchen chair. That is a masterpiece.

"The mule ear of the back legs – curved slats and back posts are a comfort to the spine. It looks good. And it is hard to do. My slats are thin and flexible. I've lost only one of them in 45 years to a split.

On chair construction:

"I interlock the tenons in a way that withstand forward and back movement – the bane of all chairs. I want every rung to share the shock. It's like grass in the wind. They all share the load."

On assembly:

"I assemble the side frames first, which is a pain in the butt. I put chairs together with a long bar clamp. The joint has a slight interference fit of .01". When you assemble it, it sounds like small arms fire – you have an oversized bone-dry tenon going into a slightly moist mortise, and drive it in squawking.

"The sides of the tenon are removed (sometimes a traditional technique) to ensure that the effective bond is between the domes of the tenon's ray plane with the end grain of the mortise. And that's the Alexander chair."



A look inside.

This cutaway sample shows how the tenons interlock in one of Alexander's chairs.

know, and it wasn't going to be a huge investment of time or money, so we agreed to jump and find out."

Kelsey and Starr traveled to Baltimore to work on the book with Alexander. Roman, the magazine's publisher, shot the photos, Alexander says. The team worked to shape up the manuscript for its 1978 release. (Upon reflecting on the process, Alexander says she was "eternally grateful" for Starr's help in particular.)

Meanwhile, Alexander continued to investigate chair technology and offered huge changes right up until the moment the book went to press – an unconventional way to make a book (or a chair for that matter).

One of the biggest last-minute changes was in how the parts were shaped. Alexander had been using a lathe to turn the components. But right before an EAIA meeting, Alexander was told she couldn't use a lathe because it was too dangerous to the audience if something flew loose.



In the country. Peter Follansbee, Theodore and Jennie during their early days at Country Workshops.

"I was down in the shop kicking stuff. I didn't know what to do," Alexander says. "Joyce gives me a cup of tea. She says, 'You shave stuff eight-sided to put it on the lathe don't you? Well keep going.'" Alexander went to the meeting and returned with a shaved chair.



Chair in use. While Peter Follansbee was the joiner at Plimoth, he would use this chair made by Alexander to explain some aspects of joinery and chair technology.

Alexander switched to shaving the chairs instead of turning them. Kelsey then had to re-write the book, Alexander says.

"But we wanted a great little gem of a book, and we didn't want to be issuing revised editions within a year or two, so we rode the pony right to the ground," Kelsey says.

"Make a Chair from a Tree" hit the market in 1978 with multiple advertisements in the magazine that were supported by articles from Drew Langsner and Alexander on green-wood techniques and technology. Kelsey says the book – 128 pages in an unusual 9" x 9" format – was a hard sell with most readers. But it was aimed right between the eyes of Peter Follansbee in Massachusetts.

"I was in my shop with a table saw and a drill press," Follansbee says. "I think I was trying to make a bookcase. With those two articles I was just captured."

Follansbee bought the book, started making chairs and in 1980 saw that Alexander was teaching a class at Country Workshops in North Carolina. Though Follansbee didn't drive a car, he found a way to the school via an airplane, two buses and 25 miles of hitchhiking and walking. In time he became a regular at the school, and he and Alexander became friends through a love for green woodworking and a twisted sense of humor.

At the time, Alexander was exploring theories of how case pieces had been made using 17th-century green woodworking techniques such as riving stock, and joinery techniques including drawboring that Benno



Early on. Alexander at Country Workshops in 1979 with Geli Courpas, her first apprentice.

Foreman, Robert Trent and Hummel at Winterthur were also researching. They helped open the door for Alexander's research in giving her access to old pieces.

"He (Alexander) was looking for someone to test his theories," Follansbee says. "He was practicing law and didn't have time to build a complex piece. So I ended up saying, 'I'll go fart around with some of this.' I had given up all my power tools. I had found a

good-sized log. He (drew out) the joint on the junk mail on his table. I rose to the bait."

That moment launched a long correspondence between Alexander and Follansbee, who would swap letters and photographs from their homes in Baltimore and Massachusetts. And eventually the letters led to the book "Make a Joint Stool from a Tree," which explored 17th-century joinery and stock preparation.

This dunking into the world of green woodworking led Follansbee to become the joiner at Plimoth Plantation for more than 20 years, where he continued to explore 17th-century furniture.

"All in all, (Alexander) has been a huge part of my life," Follansbee says.

Country Workshops

Follansbee was similar to many woodworkers who discovered green woodworking through "Make a Chair from a Tree." He started with the book and ended up studying it deeply under the direct tutelage of Alexander at Country Workshops in rural North Carolina.

Drew and Louise Langsner founded Country Workshops in 1978 shortly after the couple had written a book titled "Handmade," and Drew had just finished a book called "Country Woodcraft."

DREW LANGSNER ON POST-&-RUNG CHAIRS

When I first learned to make post-and-rung chairs I was thinking that structurally they lacked triangulation, but that (adding triangulating structures) would be very challenging with the post-and-rung construction.

It wasn't until I dug down into trying to understand Japanese timber framing that I realized that the lack of triangles ("braces" in conventional American and British timber-frames) is what makes the post-and-rung chair so sturdy. Particularly in Jennie Alexander's very light version. Under impact and load, the (chair's) frame springs around; this disperses the load over a wide area.

With triangulation, the frame is stiff and loads tend to accumulate at the triangle apexes; they can come loose. The Japanese house frame without braces flexes during their many earthquakes. The roof geometry is a big triangle, but there's no joinery up there. All the poles are lashed together and therefore wiggly when the frame below moves.

But Alexander and John Kelsey were able to show that the major stress/failure on a chair has little to do with load. It's almost all the result of countless fluctuations in moisture content within the joint.

— Drew Langsner, Country Workshops, countryworkshops.org



Ready for comfort. The back legs of Alexander's chairs are shaved to shape, steam-bent and then placed in these forms to dry, ensuring they hold their shape.

“Almost as soon as that book comes out I get a letter from John who was very excited about the book,” Drew says. The two resolved to meet when Drew traveled to New England to speak at the Woodcraft Supply store.

During the visit, Drew invited Alexander to Country Workshops to teach a class on building a simple stool. That class soon evolved into a class on building a simple chair with one slat and finally the chair that appeared on the cover of “Make a Chair from a Tree.”

And Country Workshops became the flash point for woodworkers who wanted to explore traditional woodworking in a deep way that was rooted both in tradition and science.

Even today, people come from all over the world to study chairmaking at Country Workshops, many of them inspired by Alexander’s incredibly lightweight chair.

“In fact, some students (from Australia) were here last week were sent here by Jennie,” Louise says. “She is always encouraging people. I think that is a special thing about her—generosity.

“Woodworking is such a special part of her life and she wants to share.”

So what is it about Alexander’s chair that still continues to inspire people to build it? Drew says it’s interesting to him because Alexander’s chair is es-



Sitting pretty. Alexander’s chair (foreground) with a simple antique ladderback behind. You can see both the similarities in form but the vast differences in style.

entially a historical ladderback design that appears over and over.

But Alexander was not content to just build a reproduction and call it done. Alexander, a jazz singer, likes to explore variations on a theme.

“The Appalachian chairs were a little

clunky,” Drew says. “John’s are really slender and elegant. How he came up with that look I don’t know. But the look changed everything.

“He refined the chair just perfectly.”

In fact, Drew says he’s about to start making a set of them for their house and daughter. And they were going to be exactly the same chair shown on the cover of “Make a Chair from a Tree.”

“It’s like Alexander took an old piece of music,” Drew says. “She’s following all the 300-year-old notes and making it new again.” **PWM**

Chris is the editor at Lost Art Press and is working with Alexander to produce a new revised edition of “Make a Chair from a Tree.”



Still shaving. Alexander’s Baltimore shop is light and airy, despite its location in a densely populated urban area. Green woodworking doesn’t have to happen in the country.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15


WEB SITE: Visit Jennie Alexander’s site.

TO BUY: “Make a Chair from a Tree” DVD.

WEB SITE: Take a class at Country Workshops.

Our products are available online at:

■ ShopWoodworking.com

 **THE FURNITURE INSTITUTE
of MASSACHUSETTS**

Study with Philip C. Lowe
Classes range from 1 day to 1 week
and 2 and 3 year mastery programs.

See new class schedule on:
(978) 922-0615 www.furnituremakingclasses.com

CARD #16 or go to PWFREEINFO.COM

BALTIC BIRCH
Shipped To Your Door!

- ✓ The best Baltic birch is in stock
- ✓ Get any size you want
- ✓ Friendly service
- ✓ Free shipping packs

 **100% Satisfaction Guarantee Every Order**

Easy online ordering with Woodworkers Source
www.101woods.com
PayPal 800-423-2450

CARD #53 or go to PWFREEINFO.COM

www.whitechapel-ltd.com 1(800) 468-5534


WHITECHAPEL LTD
est. 1987
Fine Brass and Iron Hardware



CARD #48 or go to PWFREEINFO.COM

Hands on Instruction for All Skill Levels

Mario Rodriguez - Alan Turner

For more info on Courses: Philadelphia Furniture Workshop
215.849.5174 

PhiladelphiaFurnitureWorkshop.com

Table Extension Slides

 **OSBORNE**
Wood Products, Inc.

1.866.963.5576
www.customlegs.com

CARD #36 or go to PWFREEINFO.COM

 **THE BEALL TOOL CO.**

541 Swans Road N.E. Newark Ohio Dept. PW
1-800-331-4718 www.bealltool.com

CARD #2 or go to PWFREEINFO.COM


Looking for wood?

VISIT
woodfinder



It's fast, easy and FREE!
www.woodfinder.com
No computer? Call toll-free 1-877-933-4637

Connecticut Valley School of Woodworking Bob Van Dyke - Director



Featuring hands-on classes for all skill levels taught by nationally known craftsmen including Peter Galbert, Steve Latta, Will Neptune, Darrell Peart and more!

249 Spencer St., Manchester, CT 06040 • 860.647.0303
www.schoolofwoodworking.com

CARD #64 or go to PWFREEINFO.COM

SABURRTOOTH®
SUPERIOR POWER CARVING TOOLS

 **saburrtooth.com**



CARD #79 or go to PWFREEINFO.COM

ICDT

**I Can Do That –
New Video Series!**

Learn the simple skills and tools you need to build great-looking projects in our new "I Can Do That" video series, with host Chad Stanton. Each episode is free on the PWM site for four weeks.



Plus, you'll find articles from the magazine, and the downloadable ICDT manual. It's all free at:
popularwoodworking.com/projects/icandothat

ICDT I Can Do That

WOODWORKER'S MARKETPLACE

CLASSIFIED

Books

WE HAVE A WIDE VARIETY of woodworking books - from small projects, to home improvement, to enhancing your woodworking skills, and more! To see our full line of books, please visit our web site at ShopWoodworking.com!

Finishing Supplies & Equipment

BLOXYGEN SAVES LEFTOVER FINISHES -

Preserve expensive varnish, paint.
www.bloxygen.com or (888) 810-8311.

SHELLAC.NET -- WOOD FINISH SUPPLY

Large Shellac Flake Selection - Brushes - Dyes
BEHLEN Finishing Supplies - Stains - Aerosols
RENAISSANCE Wax. 877-245-5611

Hand Tools

DI LEGNO WOODSHOP SUPPLY Quality
woodworking hand tools at an affordable price.
www.dlws.com or 1-412-331-1236.

WWW.JIMBODETOOLS.COM The Largest
Antique Tool Website on Earth! Fine Antique
Woodworking Tools of every kind.
845-505-8665.

Kits & Plans

FULL SIZE FURNITURE LAYOUTS Drawn by
Philip C. Lowe. 978-922-0615. 116 Water St,
Beverly, MA 01915.
www.furnituremakingclasses.com

Schools/Instruction

JOHN C. CAMPBELL FOLK SCHOOL, Brass-
town, NC. Courses for all skill levels. Week and
weekend classes year-round, taught by nation-
ally known instructors. Friendly, supportive
environment. Comfortable, on-campus hous-
ing. Delicious meals served three times a day.
www.folkschool.org. 800/365-5724.

**FRANKLIN STREET SCHOOL OF
WOODWORKING**, Tampa, FL. Group and
Private classes year round.
www.FranklinStreetFW.com. 813/223-3490.

Seat Weaving Supplies

CHAIR CANE & SPLINT, Shaker tape, fiber &
natural rush. Complete line of basketweaving
supplies. Royalwood Ltd., 517-WW Woodville
Rd, Mansfield, OH 44907. 800-526-1630.
www.royalwoodltd.com.

*Classified rate is \$6.00 per word, 15-word
minimum. Order must be accompanied by
payment; ads are non-commissionable. Send to:
Popular Woodworking Magazine, 10151 Carver
Road, Suite 200, Blue Ash, OH 45242 or Don
Schroder, d.schroder@verizon.net. Phone: 610-
821-4425, Fax: 610-821-7884.*

ADVERTISER'S INDEX

	PAGE#	CARD#	WEB ADDRESS
American Fabric Filter	15	66	americanfabricfilter.com
Beall Tool Company	56	2	bealltool.com
Bessey Tools of North America	15	101	besseytools.com
Bloxygen	57	3	bloxygen.com
Connecticut Valley School of Woodworking	56	64	schoolofwoodworking.com
Craftsman Gallery	13	-	craftsmangallery.com
Custom Branding Irons	9	93	branding-irons.biz
Di Legno Woodshop Supply	57	3	dlws.com
DR Power Equipment	17, 19	-	drpower.com
Forrest Mfg.	19	13	forrestblades.com
Franklin Street School	57	130	franklinstreetfw.com
Furniture Institute of Massachusetts	56, 57	16	furnituremakingclasses.com
GreX USA	7	20	grexusa.com
Harbor Freight	60	76	harborfreight.com
Highland Woodworker, The	19	91	thehighlandwoodworker.com
Jim Bode Tools	57	24	jimbodetools.com
John Campbell Folk School	57	0	folkschool.org
Klingspor's Wood Working Shop	15	89	woodworkingshop.com
Knew Concepts	13	60	knewconcepts.com
Lee Valley	7	28	leevalley.com
Legacy Woodworking Machinery	Cvr 4	98	legacyncwoodworking.com
Leigh Industries	13	-	leighjigs.com

	PAGE#	CARD#	WEB ADDRESS
Lie-Nielsen Toolworks	17	29	lie-nielsen.com
Lignomat USA	17	124	lignomat.com
Lumber Smith	13	112	lumbersmith.com
Mirka	Cvr 2	31	mirkawoodworking.us
Oneida Air Systems	9	35	oneida-air.com
Osborne Wood Products	7, 15, 56	36	osbornewood.com
Philadelphia Furniture Workshop	56	-	philadelphiafurnitureworkshop.com
Popular Woodturning	19	-	popularwoodturning.com
Royalwood Ltd.	57	-	royalwoodltd.com
Saburrtooth	56	79	saburrtooth.com
Shellac.net	57	-	shellac.net
Tools for Working Wood	9	45	toolsforworkingwood.com
Wall Lumber	17	47	walllumber.com
West Penn Hardwoods	13	126	westpennhardwoods.com
Whitechapel Ltd.	56	48	whitechapel-ltd.com
Woodcraft	3	49	woodcraft.com
Woodfinder	56	-	woodfinder.com
Woodpeckers	Cvr 3	52	woodpeck.com
Woodstock International	5	114	woodstockinternational.com
Woodworker's Source	56	53	woodworkerssource.com
Woodworker's Supply	9	54	woodworker.com
Woodworking In America Show	20	-	woodworkinginamerica.com

Work Begun

Forget the stockpile of wood; what about the stock of partial projects?

When building furniture, some woodworkers keep a stockpile of lumber on hand and draw from their stacks as they begin a new project. Others buy enough lumber (with some extra) for each piece they are planning to build, often working from a list that includes all the pieces in a given project and their rough dimensions. I work in a different way. I start with a log and split out almost every piece of oak that I use at the bench. Starting with the log is a lot of work, but it's even more fun.

When I split open a log, I have an idea of what my needs are, but the log often has ideas of its own. If I have a particularly large diameter, straight-grained example, then I split out and stockpile wide panels for joined work, even if I have no immediate need for panels. This approach usually results in my starting several projects at once, then leapfrogging back and forth between them.

Sometimes there are quite a few pieces underway, usually limited by shop space. When I was preparing to move my shop a year ago, I had a joined chest, a chest with drawers, a chest of drawers, two wainscot chairs, a long table and several joint stools. I finished a carved box in the midst of all these.

In one corner. This heap includes a chest with two drawers, a box front, an-almost done box with an interior till, parts for a wainscot chair, a piece or two of a chest of drawers and red oak framing stock ready to be "appointed" to any or all of these projects.



In progress. My shop is no different than those of period joiners (and likely no different than yours), with multiple works in various stages at any given time.

Most of those I finished up so I didn't have to move them. Some got stalled (the chest with drawers and the chest of drawers). I've just been back in a shop for two months and have revived those two pieces and made a large box with a drawer. Then the floodgates opened.

I now have underway the two chests, a carved box, two more wainscot chairs, a joined stool and the beginnings of two joined carved chests.

I'm not alone in this of course. I take solace that period joiners were as scattered as I am. Or more so.

In the 'Shopp'

Take the 1596 inventory of Philip Joslyn, filed in Exeter, England. The appraisers, Nicholas Baggett and Martin Garrett (alias Harman), were both joiners themselves, so we get great details:

"Item one Presse beinge half made 20s; Item certaine timber beinge appointed owt for a Table 6s8d; Item endes of timber and endes of Bourdes in the same shoppe 13s4d; Item certen Seeling in the same shopp beinge made 8s; Item half a hundred of Montens & half a hundred of stooles legges 4s."

The "Presse" is a large cupboard for clothing. These usually have doors instead of drawers, often with pegs inside for hanging clothing.

"Certen Seeling" today would be spelled "certain ceiling," but it doesn't

CONTINUED ON PAGE 61

EXCLUSIVE OFFER *now at* ShopWoodworking.com

ENJOY **10% OFF** educational products, resources, projects and more – enter code **WOODPUB10** at check-out and save 10% off select products.

SAVE 10%

Off Your Next Purchase

No minimum order
and no end date.



From the same great providers of education, articles and inspiration you experience reading *Popular Woodworking Magazine*, **check out ShopWoodworking.com and save now!**

Promo Code Exclusions Apply: Your special discount/coupon code will allow you to take 10% OFF many (not all) of the items you find at ShopWoodworking.com. Your discount/coupon code is not valid for purchasing gift cards, subscriptions, pre-orders, value packs, VIP memberships, or items that ship directly from manufacturers. Discounts cannot be applied to previous purchases. Valid for one use per customer only. Other exclusions may apply.

HARBOR FREIGHT

QUALITY TOOLS AT RIDICULOUSLY LOW PRICES

**How Does Harbor Freight
Sell GREAT QUALITY Tools
at the LOWEST Prices?**

We have invested millions of dollars in our own state-of-the-art quality test labs and millions more in our factories, so our tools will go toe-to-toe with the top professional brands. And we can sell them for a fraction of the price because we cut out the middle man and pass the savings on to you. It's just that simple! Come visit one of our 550 Stores Nationwide.

SCISSOR SUPER COUPON

20% OFF

ANY SINGLE ITEM

LIMIT 1 - Save 20% on any one item purchased at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount, coupon, gift cards, Inside Track Club membership, extended service plans or on any of the following: compressors, generators, tool storage or carts, welders, floor jacks, Towable Ride-On Trencher, Saw Mill (Item 61712/62366/67138), Predator Gas Power Items, open box items, in-store event or parking lot sale items. Not valid on prior purchases after 30 days from original purchase date with original receipt. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

FREE

WITH **ANY** PURCHASE
**3-1/2" SUPER BRIGHT
NINE LED
ALUMINUM
FLASHLIGHT**

Item 69052 shown
ITEM 69052
69111/62522

\$6.99

VALUE

LIMIT 1 - Cannot be used with other discount, coupon or prior purchase. Coupon good at our stores, HarborFreight.com or by calling 800-423-2567. Offer good while supplies last. Shipping & Handling charges may apply if not picked up in-store. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one FREE GIFT coupon per customer per day.

SCISSOR SUPER COUPON

PITTSBURGH

24" CLAMP AND CUT EDGE GUIDE

LOT NO. 66126

SAVE 53%

\$6.99

REG. PRICE \$14.99

Item 92153578 shown

LIMIT 3 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

US* GENERAL PRO

30", 5 DRAWER TOOL CART

*** WINNER ***
Best Mechanic's
Tool Cart
Truckin' Magazine

LOT NO. 95272
69397
61427

SAVE \$185

\$164.99

REG. PRICE \$349.99

Item 95272 shown

• 704 lb. Capacity

LIMIT 4 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

PITTSBURGH

16 OZ. HAMMERS WITH FIBERGLASS HANDLE

CLAW **RIP**

LOT NO. 47872
69006/60715/60714

LOT NO. 47873
69005/61262

SAVE 62%

\$2.99

REG. PRICE \$7.99

Item 47872 shown

YOUR CHOICE!

LIMIT 7 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

GENERAL MACHINERY

2 HP INDUSTRIAL 5 MICRON DUST COLLECTOR

• 70 Gallon Capacity

LOT NO. 97869/61790

SAVE \$90

\$159.99

REG. PRICE \$249.99

Item 97869 shown

LIMIT 3 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

WINDSOR DESIGN

60" WORKBENCH WITH FOUR DRAWERS

LOT NO. 93454
69054

SAVE \$110

\$139.99

REG. PRICE \$249.99

Item 93454 shown

LIMIT 4 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

**2.5 HP, 21 GALLON
125 PSI VERTICAL
AIR COMPRESSOR
CENTRALPNEUMATIC**

LOT NO. 67847
61454/61693

SAVE \$70

\$149.99

REG. PRICE \$219.99

Item 67847 shown

LIMIT 5 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

**1/4" TRIM ROUTER
drillmaster**

LOT NO. 44914/61626

SAVE 42%

\$19.99

REG. PRICE \$34.99

Item 44914 shown

LIMIT 3 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

**10" SLIDING
COMPOUND
MITER SAW**

CHICAGO ELECTRIC POWER TOOLS

LOT NO. 98199
98199/61307
61971/61972

SAVE \$115

\$84.99

REG. PRICE \$199.99

Item 98199 shown

LIMIT 5 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

HaulMaster

72" x 80" MOVER'S BLANKET

LOT NO. 66537
69505/62418

SAVE 66%

\$5.99

REG. PRICE \$17.99

Item 66537 shown

LIMIT 6 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

NEW

900 PEAK/ 700 RUNNING WATTS 2 HP (63 CC) 2 CYCLE GAS RECREATIONAL GENERATOR

LOT NO. 69381
60338/62472/66619

SAVE \$80

\$99.99

REG. PRICE \$179.99

Item 69381 shown

LIMIT 4 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

CHICAGO ELECTRIC

90 AMP FLUX WIRE WELDER

• No Gas Required

LOT NO. 68887
61849

WE CARRY A FULL LINE OF WELDING WIRE

\$99.99

REG. PRICE \$149.99

Item 68887 shown

LIMIT 3 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.

SCISSOR SUPER COUPON

PITTSBURGH AUTOMOTIVE

RAPID PUMP® 3 TON HEAVY DUTY STEEL FLOOR JACK

LOT NO. 68048/69227/62116

SAVE \$85

\$74.99

REG. PRICE \$159.99

Item 68048 shown

• Weighs 74 lbs.

LIMIT 5 - Good at our stores or HarborFreight.com or by calling 800-423-2567. Cannot be used with other discount or coupon or prior purchases after 30 days from original purchase with original receipt. Offer good while supplies last. Non-transferable. Original coupon must be presented. Valid through 6/17/15. Limit one coupon per customer per day.


• 100% Satisfaction Guaranteed
• Over 25 Million Satisfied Customers

• No Hassle Return Policy
• Lifetime Warranty On All Hand Tools

• 550 Stores Nationwide
• HarborFreight.com 800-423-2567



Wainscot. The hall in the Merchant's House (Marlborough, Wiltshire) shows period wainscoting; a room or two like this could easily use "half a hundred" muntins. The inset photo (below) shows a cross-section of a wainscot muntin (notice the drawbore holes).



mean the part of a room over your head. It refers to wainscoting or paneling on hand, presumably already dedicated to a particular room, hence "certain." Joiners in the 16th and 17th centuries were often called by the double moniker "joiner and ceiler."

The 50 "Montens" are muntins – the short intermediate framing parts, perhaps for more of the wainscoting.

The stools' legs are the squared sections for joint stools, maybe already mortised and turned.

Also, the quantities can throw you. "Half a hundred" could be 60 pieces. In many cases a "hundred" is six-score, i.e. 120 pieces.

In 1613, Anthony Ould, of Worcester, England, had half-finished work and timber on hand when he died. Listed in his inventory were:

"In both the shoppes: two standing bedes finesht £2-6, on(e) liverye bed

steed 5s, two bed steeds begune 6s, on(e) presse begune 13s4d, two payer of pyllars and other worke 19s, panels £2-16-7, rayles £4-11-4, 2 inche planckes of wallnut tree £2, halfe inch bordes of wallnut tree 6s8d, inch and quarter of wallnut tree 15s, two oaken planks 4s9d, certayne other peces of tymber £4, turned and carved worke 12s8d, more odd tymber 6s."

That's a lot of bedsteads underway at once; he must have had a fair amount of room available. A press is also substantial. The pillars could be large turned work for the bedsteads, but also could be turned parts for cupboards. Like the previous inventory, this one includes

stock processed into framing parts, this time rails and panels. The price comparison between the rails (£4/11/4) and the finished bedsteads (£2/6) tells us there's a lot of rail stocked prepped ahead in this shop.

Over in New England, the trend continued. In 1671, John Symonds, of Salem, Mass., had "2 Bedsteads almost finished £3" and "3 stools and one half of a Box 12s6d; Timber planke & board £5-12." His inventory also included "part of a Chest... Timber in the Woods £1-2, an apprentice of 17 years old who hath 3 year and 9 moneths and 2 weekes to serve."

For me, it's more fun starting projects than finishing them. Ultimately, I get to the point where I'll settle down and finish off pieces in rapid-fire succession. For a brief time, it really looks like I know what I'm doing. But were an inventory of my "shopp" to land in front of a curious craftsman 400 years from now, pretty much the only thing that would distinguish it from Joslyn's or Ould's lists would be the currency, and the spelling of "presse" and "wallnut." **PWM**

Peter has been involved in traditional craft since 1980. Read more from him on spoon carving, period tools and more at pfollansbee.wordpress.com.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

BLOG: Read Peter Follansbee's blog.

TO BUY: "17th Century New England Carving: Carving the S-Scroll" (Lie-Nielsen).

IN OUR STORE: "The Arts & Mysteries of Hand Tools" on CD.

About this Column

ARTS & Mysteries

"Arts & Mysteries" refers to the contract between an apprentice and master – the 18th-century master was contractually obligated to teach apprentices trade secrets of a given craft (and the apprentice was expected to preserve those "mysteries").

Our products are available online at:

■ ShopWoodworking.com



In progress. One piece "begun" is this chest of drawers. This is the upper case, still lacking some applied ornament and the top boards.



Chest build. Here's a joined chest – or three-quarters of one, at least. Finish the rear framing, a lid and bottom, and off it goes.

Why is Finishing So Difficult?

Misleading claims and directions may be due to manufacturer ignorance.

In the previous issue (#216) I wrote about teak oils and how none have anything to do with teak wood. Reading the article, you may have asked yourself why companies would put out products that aren't what they say they are and don't do what they say they do.

I used to think the people at these companies knew better and did this to fool us. But after more than 25 years of dealing with them, I've come to believe that many who target the DIY market just don't understand their products. The companies aren't actually finish companies; they're marketing companies. They just sell stuff, using whatever labeling or claims they think will work.


How can they do this and get away with it, you ask? In my opinion it's because finishes are chemistry – in contrast to woodworking, for example, which is physics. You can see that a band saw isn't a table saw, even though it, too, has a table. But you can't see the difference between varnish and lacquer, either in the can or on the wood – and they are very different finishes.

Because many marketing people have little understanding (even though their products are usually very good), we, the users, struggle. How else can you explain the following examples?

Watco Danish Oil

Watco Danish Oil was introduced to the woodworking community in the second issue of *Fine Woodworking* in 1976. The application directions in the article were good, and they have been repeated by writers and teachers countless times since: Apply a wet coat; let it soak in; wipe off; let dry overnight; sand smooth; apply a second coat, and maybe a third after another day.

But the directions on the Watco can were (and still are): Apply a wet coat;



Watco Danish Oil. The application method Watco suggests on its label is a two-step single coat, both steps applied within 45 minutes. This results in a slightly duller and clearly rougher feeling surface (left half of surface) than the better application method (right half of panel) suggested by experienced woodworkers for nearly 40 years.



Minwax Wood Conditioner. The company says to apply the stain within two hours of applying the conditioner. Shown on this panel, left to right, is the stain applied directly to the wood; immediately after applying the conditioner; after 10 minutes; after two hours, and finally after overnight drying. Notice that the blotching actually gets worse (because of the evaporation of the thinner) the longer the elapsed time until the thinned-varnish conditioner has fully dried.

wait 30 minutes; reapply; wipe dry after 15 minutes. This doesn't produce good results because it's really just one coat. The first hasn't dried before the second is applied. The full sheen and smoothness of any finish isn't produced until a second coat is applied over a dry and sanded first coat.

But in nearly 40 years, as Watco was bought and sold by many companies, (It's now owned by Rust-Oleum), these directions never changed.

Minwax Wood Finish & Wood Conditioner

Minwax has also been bought and sold many times, most recently bought by Sherwin-Williams. But the name, "Wood Finish," on their yellow cans of stain has never been changed to reflect what the product really is – a stain. Though experienced woodwork-

ers know this, the mislabeling causes confusion for beginners.

Minwax also makes "Wood Conditioner" and provides instructions on the can for avoiding blotching. Apply a wet coat; wipe dry after five to 15 minutes; apply the stain within two hours.

These directions don't work well. The wood conditioner is varnish thinned with about two parts mineral spirits. It requires six hours to overnight to dry and become effective at reducing blotching.

3M Safest Stripper

3M Safest Stripper was introduced in the early 1990s as a substitute for strippers based on methylene chloride, which was a suspected carcinogen. The stripper is almost unique in that it contains 65 percent water.

Apparently no one at 3M understood

the relationship between water, wood and paint stripping.


Safest Stripper works very slowly, so it has to be left in contact for a long time. This can cause veneer to lift, especially on old furniture (pre-1950) glued with animal hide glue, and it causes steel wool to rust and leave black marks on the wood. The formulators had apparently been using 3M's own Scotch-Brite pads, and no one had enough experience with stripping to realize that most people use steel wool.

Olympic Stain

Olympic Stain had been the best-known deck stain for decades. When PPG bought it in the mid-1990s, they did a survey and found that Olympic was the second best-known interior stain behind Minwax, even though



3M Safest Stripper. Because of the high percentage of water in this paint and varnish remover, steel wool used for scrubbing off the sludge rusts and causes black marks on the wood. This caught the manufacturer by surprise. To fix the problem, 3M put this warning sticker on the cap.



Olympic Stain. This is a part of the ad Olympic Stain ran in woodworking magazines to introduce their interior stain. The oak on the left is blotched, but oak doesn't blotch. The only ways I can think of to get oak to look like this are to do a poor job of sanding or generate the image on a computer.

Olympic didn't make interior stains.

Being good marketers, they quickly introduced a line of interior products modeled after Minwax, and they advertised for months in woodworking magazines with one- and two-page advertising spreads.

Highlighted in the ads were two pictures of oak, one blotched with an "ordinary" stain, the other an even color with their "absorption-control" stain. The problem is that oak doesn't blotch! Apparently, no one at Olympic knew this. Pine and cherry blotch, and Olympic stain blotches them just as all liquid stains do.

Carver Tripp Safe & Simple

Carver Tripp was once a prominent finish company sponsoring Norm Abram. The company made a water-based wood stain called Safe & Simple. One big issue with water-based stains was, and still is, that they raise the grain of the wood. So Carver Tripp dealt with this problem by simply claiming on the label that their stain "never harms the wood or raises the wood grain."

Did no one at Carver Tripp know enough about water and wood to realize that making such an obviously false claim might not be a wise thing to do? Carver Tripp no longer exists.

General Finishes Seal-a-Cell

When I was writing "Understanding Wood Finishing" in 1993, I called General Finishes to ask about Seal-a-Cell,



Seal-a-Cell wiping varnish. The way to tell if a finish that thins and cleans up with mineral spirits is oil or varnish is to put a puddle on a non-porous surface. If the puddle dries soft and wrinkled, it's oil or oil/varnish blend. If the puddle dries hard and smooth, it's varnish. This is clearly varnish despite the claims of the manufacturer.

which was, and still is, represented as an oil sealer that "penetrates deep within the wood." But a puddle dries hard and smooth, so it had to be varnish. (Varnish is made with oil, but it's no longer oil and the oil part can't act separately.)

To prove that the finish was oil, the owner told me the main ingredient: alkyd-modified linseed oil. This, of course, is a more technical name for varnish! He didn't know.

I think it's manufacturer ignorance that is most responsible for making finishing so difficult to understand. This explains why the help you get when you call these companies is so poor.

The products are good; the instructions and claims are not. **PWM**

Bob is author of "Flexner on Finishing," "Wood Finishing 101" and "Understanding Wood Finishing."



Carver Tripp water-based stain. To deal with the problem of water-based stains raising the grain of the wood, the marketers at Carver Tripp simply said theirs didn't. Did no one try the stain or realize how obviously false this claim is and that making it might damage the reputation of the company?

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

ARTICLES: You'll find many free finishing articles on our web site.

IN OUR STORE: "Flexner on Finishing" – 12 years of columns illustrated with beautiful full-color images and updated, and "Wood Finishing 101."

Our products are available online at:

■ ShopWoodworking.com

Why I Love Ikea

Lessons from a big box guide my approach to woodworking.

I love Ikea. Yes, I said it.

This store has provided me with an understanding of furniture design and with products I use on many of my projects. For some I'm happy to pay, but for most I haven't had to pay a penny.

I first became aware of furniture design while walking our dog. Seriously. To get to the off-leash park, we walked down back lanes.

I was alarmed at the sheer quantity of discarded furniture—Ikea furniture, to be precise. I began to examine this stuff more closely, and gradually a pattern emerged.

From this pattern I formed a “law” of furniture design. Take, for example, Ikea beds: Pieces broke right where the mechanical fasteners were placed. Well, it figured, two kids jumping on a bed = dynamic load. Therefore, dynamic load + barficle-board + mechanical fasteners + time = garbage.

I learned about chair construction—actually how not to construct a chair—while working at Chez Phillippe, a cozy French bistro. Maybe it was serendipity that caused me to observe how Ikea chairs failed, but I made the necessary observations seated on the “throne.”

When a chair failed, the waiters hauled it off to our tiny staff washroom. At any given time, there were five failed chairs crammed into that tiny john.

The owner would salvage what he could from broken chairs and re-assemble a single one. Missing chairs were replaced with the same Ikea model and given a coat of lime-green paint (to match the decor of Chez Phillippe).

There were three major causes of failure: First was choice of materials; the chairs were softwood, pine I think. Again, wood around the mechanical fasteners failed, or wood was com-



pressed and then racked, and fasteners would fall out.

Second is that dowels make lousy joinery for dynamic loads; they invariably failed.

Third is poor stock selection. The curved rear legs almost always failed because of grain runout. After a year working there, I had opportunity to examine how nearly 80 identical chairs failed, and it never cost me a dime. Not an armchair detective, but close.

As I became more proficient with tools and had time to make projects, I began to see discarded furniture in the back lanes in a different light—as a resource. I haven't bought cup hinges in 10 years now—same with drawer glides, knobs, and pulls.

Ah, but wood, you ask, can real wood be salvaged from Ikea castoffs? Yes, there is some real wood in Ikea furniture.

Discarded beds come with solid spruce bed slats, which are just under 3/4" thick, 34" long, and about 3" wide. I have built numerous projects with these.

Hardwood? Yes. To build my bow

saw, I bought the hardware, like many others do, from Tools For Working Wood. But the beech for my saw came from Ikea. Actually, it came from my neighbor when he tossed out his Ikea Poäng armchair. There was even enough left over to make an English layout square.

So when do I actually make a trip to the big blue and yellow box and fork out money? I do it for one, and only one item: Numerär. That's the 1 1/2"-thick countertop in solid beech or birch. It's not furniture; it's building material.

As a result, I'm grateful for Ikea. Just not for the reasons Ikea wants me to be. **PWM**

While Edward has splurged for “real” lumber in some projects, others are made from furniture he finds while walking his dog in Vancouver, British Columbia.

ONLINE EXTRAS

For links to all online extras, go to:

■ popularwoodworking.com/apr15

TWITTER: Follow us on Twitter @pwweditors.

Our products are available online at:

■ ShopWoodworking.com


Assemble Projects the Easy Way

Our Box Clamps Streamline Glue-ups,
Guarantee Square Assembly Every Time

Woodpeckers®

BC4-M2 Box Clamp

Made in America



Like Having an Extra Pair of Hands. With our new M2 Box Clamps you can glue-up or dry-fit any 90° joint quickly and easily and know your joint is square. Just position the clamp in the corner of the joint, give the knob a twist and equal pressure is applied while instantly squaring the joint. It's that simple.

Our M2 Box Clamp Has Many Uses. These clamps work great on butt joints, miters, dados, rabbets; through or half-blind dovetails and box joints even when material overhangs the joint face. Its design let's you easily nail or screw along the full length of the joint. And if you are a fan of pocket-hole joinery, our Box Clamps are the answer to your prayers.



Rugged with A Full Range of Adjustment. Our clamps are molded using a nearly indestructible glass fiber filled polycarbonate. The Box Clamp quickly adjusts for use with material ranging in thickness from ¼" to a full 1". An easy twist of the knob or hex key (depending on clamping application) provides ample torque to tighten the clamp and secure the work.

When you want square corners you just can't beat Woodpeckers M2 Box Clamps. Watch how simple and handy they are to use at <http://www.woodpeck.com/boxclampm2.html>

See our full line of American made woodworking tools at www.woodpeck.com

11050 Industrial First Ave. • North Royalton, Ohio 44133 • (800) 752-0725

CARD #52 or go to PWFREEINFO.COM

Legacy Woodworking Machinery's Explorer CNC Woodworking System

The world's *FIRST* complete CNC System

Shown with a "whisper quiet",
liquid cooled, 3HP, high
performance spindle.

- ROUTING
- MILLING
- JOINING
- TURNING
- 3D CARVING
- ROTARY CARVING
- FRETWORK
- TURNING



25" x 25" or 25" x 50"
worktable available.

See the *Explorer CNC*
build this dining chair
project at legacync-woodworking.com



Join our **FREE** online training classes taught twice each
week by our own team of CAD/CAM experts



Legacy's *Explorer CNC System* tackles all your
most difficult and important woodworking
jobs on a single CNC platform.

Start with a welded steel frame routing table
for mill work, 3-D carving, fretwork, and inlay.

Add the world's first integrated joinery system
which combines panel joinery features with
compound angle mortise and tenon
capabilities.

Add a rotary axis to turn round spindles and
create rotary carvings, indexing capabilities
for milling multi-sided spindles, cutting fluted,
reeds, and adding spindle joinery.

When combined, these systems become the
most powerful CNC woodworking tool you
can own. Put one in your workshop today.

Base Systems starting at \$3995



Milling the chair back stiles on
the horizontal worktable.



Cutting the back splat mortise
with the panel clamp.



Using the turning system to mill the
legs and mortise/tenon joints.



Cutting the straight tenon on
the vertical work table.

